



Depth of Field Tables in Meter

for

Compact Prime Lenses CP.2

for

	MFT format	ANSI Super 35, Normal 35, APS-H and APS-C Format	Full Format
CP.2 T3.6/18 mm	■	■	
CP.2 T2.9/21 mm	■	■	■
CP.2 T2.9/25 mm	■	■	■
CP.2 T2.1/28 mm	■	■	■
CP.2 T2.1/35 mm	■	■	■
CP.2 T2.1/50 mm	■	■	■
CP.2 T2.1/85 mm	■	■	■
CP.2 T2.1/100 mm	■	■	■
CP.2 T2.1/50 mm Makro	■	■	■

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 18/T3.6 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	3.6		4		5.6	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	4.91	INF	4.36	INF	4.87	INF
10	3.33	INF	3.07	INF	3.31	INF
6	2.74	INF	2.56	INF	2.73	INF
4	2.24	21.27	2.12	18.17	2.23	INF
3	1.90	7.52	1.81	7.09	1.89	INF
2.5	1.69	4.95	1.63	4.77	1.69	92.38
2	1.45	3.28	1.40	3.20	1.45	8.52
1.8	1.35	2.76	1.31	2.70	1.34	5.67
1.6	1.24	2.30	1.20	2.26	1.23	3.99
1.4	1.12	1.90	1.09	1.87	1.11	2.90
1.3	1.05	1.72	1.03	1.69	1.05	2.48
1.2	0.99	1.54	0.97	1.52	0.99	2.12
1.1	0.92	1.38	0.9	1.36	0.92	1.81
1	0.85	1.22	0.84	1.21	0.85	1.54
0.95	0.82	1.14	0.8	1.13	0.82	1.42
0.9	0.78	1.07	0.77	1.06	0.78	1.3
0.85	0.74	1	0.73	0.99	0.74	1.2
0.8	0.71	0.93	0.7	0.92	0.71	1.09
0.75	0.67	0.86	0.66	0.85	0.67	1
0.7	0.63	0.79	0.62	0.79	0.63	0.91
0.65	0.59	0.73	0.58	0.72	0.59	0.82
0.6	0.55	0.66	0.54	0.66	0.55	0.74
0.58	0.53	0.64	0.53	0.64	0.53	0.71
0.56	0.52	0.61	0.51	0.61	0.52	0.67
0.54	0.5	0.59	0.5	0.59	0.5	0.64
0.52	0.48	0.56	0.48	0.56	0.48	0.61
0.5	0.47	0.54	0.46	0.54	0.47	0.59
0.48	0.45	0.52	0.45	0.51	0.45	0.56
0.46	0.43	0.49	0.43	0.49	0.43	0.53
0.44	0.41	0.47	0.41	0.47	0.41	0.5
0.42	0.4	0.45	0.39	0.44	0.4	0.47
0.4	0.38	0.42	0.38	0.42	0.38	0.45
0.39	0.37	0.41	0.37	0.41	0.37	0.43
0.38	0.36	0.4	0.36	0.4	0.36	0.42
0.37	0.35	0.39	0.35	0.39	0.35	0.41
0.36	0.34	0.38	0.34	0.38	0.34	0.4
0.35	0.34	0.37	0.33	0.37	0.34	0.38
0.34	0.33	0.36	0.33	0.35	0.33	0.37
0.33	0.32	0.34	0.32	0.34	0.32	0.36
0.32	0.31	0.33	0.31	0.33	0.31	0.35
0.31	0.3	0.32	0.3	0.32	0.3	0.33
0.3	0.29	0.31	0.29	0.31	0.29	0.32

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 18/T3.6 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	8		11		16	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	6.41	INF	4.44	INF	2.43	INF
10	3.94	INF	3.11	INF	1.98	INF
6	3.13	INF	2.59	INF	1.76	INF
4	2.50	INF	2.14	INF	1.55	INF
3	2.07	INF	1.83	INF	1.38	INF
2.5	1.83	INF	1.63	INF	1.27	INF
2	1.55	INF	1.41	INF	1.13	INF
1.8	1.43	INF	1.31	INF	1.07	INF
1.6	1.30	INF	1.20	INF	1.00	INF
1.4	1.17	20.36	1.09	INF	0.92	INF
1.3	1.10	9.05	1.03	INF	0.88	INF
1.2	1.03	5.49	0.97	INF	0.84	INF
1.1	0.96	3.75	0.9	INF	0.79	INF
1	0.88	2.72	0.84	11.34	0.74	INF
0.95	0.84	2.34	0.8	6.69	0.71	INF
0.9	0.8	2.03	0.77	4.59	0.69	INF
0.85	0.76	1.77	0.73	3.4	0.66	INF
0.8	0.73	1.55	0.7	2.64	0.63	13.09
0.75	0.68	1.35	0.66	2.1	0.6	5.61
0.7	0.64	1.18	0.62	1.7	0.57	3.4
0.65	0.6	1.03	0.58	1.4	0.54	2.34
0.6	0.56	0.9	0.54	1.16	0.5	1.71
0.58	0.54	0.85	0.53	1.08	0.49	1.53
0.56	0.53	0.81	0.51	1	0.48	1.37
0.54	0.51	0.76	0.49	0.93	0.46	1.24
0.52	0.49	0.72	0.48	0.86	0.45	1.12
0.5	0.47	0.68	0.46	0.8	0.44	1.01
0.48	0.46	0.64	0.45	0.74	0.42	0.92
0.46	0.44	0.6	0.43	0.69	0.41	0.84
0.44	0.42	0.56	0.41	0.64	0.39	0.76
0.42	0.4	0.53	0.39	0.59	0.38	0.69
0.4	0.38	0.49	0.38	0.55	0.36	0.63
0.39	0.37	0.48	0.37	0.53	0.35	0.6
0.38	0.37	0.46	0.36	0.51	0.35	0.57
0.37	0.36	0.44	0.35	0.49	0.34	0.55
0.36	0.35	0.43	0.34	0.47	0.33	0.52
0.35	0.34	0.41	0.33	0.45	0.32	0.5
0.34	0.33	0.4	0.32	0.43	0.31	0.47
0.33	0.32	0.38	0.32	0.41	0.31	0.45
0.32	0.31	0.37	0.31	0.39	0.3	0.43
0.31	0.3	0.35	0.3	0.38	0.29	0.41
0.3	0.29	0.34	0.29	0.36	0.28	0.39

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 18/T3.6 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.40	INF
10	1.24	INF
6	1.16	INF
4	1.07	INF
3	0.99	INF
2.5	0.93	INF
2	0.86	INF
1.8	0.82	INF
1.6	0.78	INF
1.4	0.74	INF
1.3	0.71	INF
1.2	0.68	INF
1.1	0.65	INF
1	0.62	INF
0.95	0.6	INF
0.9	0.58	INF
0.85	0.56	INF
0.8	0.54	INF
0.75	0.52	INF
0.7	0.5	INF
0.65	0.48	19.44
0.6	0.45	4.61
0.58	0.44	3.44
0.56	0.43	2.7
0.54	0.42	2.2
0.52	0.41	1.83
0.5	0.4	1.55
0.48	0.39	1.33
0.46	0.37	1.15
0.44	0.36	1.01
0.42	0.35	0.89
0.4	0.34	0.78
0.39	0.33	0.74
0.38	0.32	0.69
0.37	0.32	0.65
0.36	0.31	0.61
0.35	0.3	0.58
0.34	0.3	0.55
0.33	0.29	0.51
0.32	0.28	0.48
0.31	0.28	0.46
0.3	0.27	0.43

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 21/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	8		11		16	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	5.94	INF	3.93	INF	2.48	INF
10	3.78	INF	2.86	INF	2.02	INF
5	2.77	INF	2.25	INF	1.71	INF
3	2.04	INF	1.75	INF	1.41	INF
2	1.54	10.55	1.37	INF	1.16	INF
1.7	1.36	5.23	1.23	28.18	1.06	INF
1.5	1.23	3.61	1.13	8.05	0.98	INF
1.3	1.10	2.57	1.02	4.17	0.90	19.62
1.1	0.95	1.85	0.89	2.51	0.81	4.65
1	0.88	1.56	0.83	2.00	0.76	3.11
0.9	0.80	1.31	0.76	1.60	0.70	2.21
0.8	0.73	1.1	0.69	1.28	0.64	1.63
0.75	0.69	1	0.66	1.14	0.61	1.41
0.7	0.64	0.9	0.62	1.02	0.58	1.22
0.65	0.6	0.82	0.58	0.91	0.55	1.05
0.6	0.56	0.73	0.54	0.8	0.51	0.91
0.55	0.52	0.65	0.5	0.71	0.48	0.79
0.5	0.47	0.58	0.46	0.62	0.44	0.68
0.48	0.46	0.55	0.45	0.59	0.43	0.63
0.46	0.44	0.52	0.43	0.55	0.41	0.59
0.44	0.42	0.5	0.41	0.52	0.4	0.56
0.42	0.4	0.47	0.4	0.49	0.38	0.52
0.4	0.39	0.44	0.38	0.46	0.37	0.49
0.39	0.38	0.43	0.37	0.45	0.36	0.47
0.38	0.37	0.42	0.36	0.43	0.35	0.45
0.37	0.36	0.4	0.35	0.42	0.34	0.44
0.36	0.35	0.39	0.34	0.4	0.34	0.42
0.35	0.34	0.38	0.34	0.39	0.33	0.41
0.34	0.33	0.37	0.33	0.38	0.32	0.39
0.33	0.32	0.35	0.32	0.36	0.31	0.38
0.32	0.31	0.34	0.31	0.35	0.3	0.36
0.31	0.3	0.33	0.3	0.34	0.29	0.35
0.3	0.29	0.32	0.29	0.32	0.29	0.33
0.29	0.28	0.31	0.28	0.31	0.28	0.32
0.28	0.27	0.29	0.27	0.3	0.27	0.31
0.27	0.27	0.28	0.26	0.29	0.26	0.29
0.26	0.26	0.27	0.25	0.27	0.25	0.28
0.25	0.25	0.26	0.24	0.26	0.24	0.27
0.24	0.24	0.25	0.24	0.25	0.23	0.26

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 21/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.63	INF
10	1.42	INF
5	1.27	INF
3	1.10	INF
2	0.95	INF
1.7	0.88	INF
1.5	0.83	INF
1.3	0.77	INF
1.1	0.71	INF
1	0.67	14.37
0.9	0.63	4.83
0.8	0.58	2.65
0.75	0.56	2.08
0.7	0.53	1.68
0.65	0.51	1.37
0.6	0.48	1.13
0.55	0.45	0.93
0.5	0.42	0.77
0.48	0.41	0.72
0.46	0.39	0.67
0.44	0.38	0.62
0.42	0.37	0.57
0.4	0.35	0.53
0.39	0.35	0.51
0.38	0.34	0.49
0.37	0.33	0.47
0.36	0.32	0.45
0.35	0.32	0.43
0.34	0.31	0.41
0.33	0.3	0.4
0.32	0.29	0.38
0.31	0.29	0.36
0.3	0.28	0.35
0.29	0.27	0.33
0.28	0.26	0.32
0.27	0.25	0.3
0.26	0.25	0.29
0.25	0.24	0.27
0.24	0.23	0.26

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 25/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.94	INF
4	1.35	INF
2	1.03	INF
1.3	0.82	10.54
1	0.70	2.79
0.8	0.60	1.56
0.7	0.55	1.18
0.6	0.49	0.90
0.55	0.46	0.78
0.5	0.43	0.67
0.45	0.39	0.57
0.4	0.36	0.49
0.38	0.34	0.45
0.36	0.33	0.42
0.34	0.31	0.39
0.32	0.3	0.36
0.3	0.28	0.34
0.29	0.27	0.32
0.28	0.26	0.31
0.27	0.26	0.29
0.26	0.25	0.28
0.25	0.24	0.27
0.24	0.23	0.26
0.23	0.22	0.24
0.22	0.21	0.23
0.21	0.2	0.22
0.2	0.19	0.21
0.19	0.19	0.2
0.18	0.18	0.18
0.17	0.17	0.17

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 28/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	15.19	INF	10.87	INF	6.63	INF
10	6.07	INF	5.25	INF	4.03	INF
5	3.79	52.01	3.46	INF	2.89	INF
3	2.53	6.36	2.38	12.26	2.10	INF
2	1.79	3.03	1.71	3.9	1.57	5.78
1.6	1.46	2.18	1.41	2.58	1.32	3.26
1.4	1.3	1.81	1.26	2.08	1.18	2.49
1.2	1.12	1.48	1.1	1.65	1.04	1.89
1	0.95	1.18	0.93	1.28	0.89	1.42
0.9	0.86	1.04	0.84	1.11	0.81	1.21
0.8	0.77	0.91	0.76	0.96	0.73	1.03
0.75	0.72	0.84	0.71	0.89	0.69	0.94
0.7	0.68	0.78	0.67	0.81	0.65	0.86
0.65	0.63	0.71	0.62	0.74	0.61	0.78
0.6	0.6	0.7	0.6	0.7	0.6	0.7
0.55	0.5	0.6	0.5	0.6	0.5	0.6
0.5	0.5	0.5	0.5	0.6	0.5	0.6
0.48	0.5	0.5	0.5	0.5	0.5	0.5
0.46	0.45	0.49	0.45	0.5	0.44	0.51
0.44	0.43	0.46	0.43	0.47	0.42	0.49
0.42	0.41	0.44	0.41	0.45	0.4	0.46
0.4	0.39	0.42	0.39	0.43	0.39	0.44
0.39	0.38	0.41	0.38	0.41	0.38	0.42
0.38	0.37	0.4	0.37	0.4	0.37	0.41
0.37	0.36	0.38	0.36	0.39	0.36	0.4
0.36	0.36	0.37	0.35	0.38	0.35	0.39
0.35	0.35	0.36	0.34	0.37	0.34	0.37
0.34	0.34	0.35	0.33	0.36	0.33	0.36
0.33	0.3	0.3	0.3	0.3	0.3	0.4
0.32	0.3	0.3	0.3	0.3	0.3	0.3
0.31	0.3	0.3	0.3	0.3	0.3	0.3
0.3	0.3	0.3	0.3	0.3	0.3	0.3
0.29	0.29	0.3	0.29	0.3	0.28	0.3
0.28	0.28	0.29	0.28	0.29	0.27	0.29
0.27	0.27	0.28	0.27	0.28	0.27	0.28
0.26	0.26	0.26	0.26	0.27	0.26	0.27
0.25	0.25	0.25	0.25	0.26	0.25	0.26
0.24	0.24	0.24	0.24	0.25	0.24	0.25

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 28/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	4.09	INF	2.63	INF
10	2.94	INF	2.11	INF
5	2.29	INF	1.76	INF
3	1.77	INF	1.45	INF
2	1.38	15.39	1.18	INF
1.6	1.19	4.97	1.04	18.47
1.4	1.08	3.35	0.96	6.49
1.2	0.96	2.34	0.86	3.48
1	0.83	1.64	0.76	2.11
0.9	0.76	1.37	0.71	1.68
0.8	0.69	1.14	0.65	1.33
0.75	0.66	1.03	0.61	1.19
0.7	0.62	0.93	0.58	1.05
0.65	0.58	0.84	0.55	0.93
0.6	0.5	0.8	0.5	0.8
0.55	0.5	0.7	0.5	0.7
0.5	0.5	0.6	0.4	0.6
0.48	0.5	0.6	0.4	0.6
0.46	0.43	0.53	0.41	0.56
0.44	0.41	0.5	0.4	0.53
0.42	0.4	0.48	0.38	0.5
0.4	0.38	0.45	0.37	0.47
0.39	0.37	0.44	0.36	0.45
0.38	0.36	0.42	0.35	0.44
0.37	0.35	0.41	0.34	0.42
0.36	0.34	0.4	0.33	0.41
0.35	0.33	0.38	0.33	0.4
0.34	0.33	0.37	0.32	0.38
0.33	0.3	0.4	0.3	0.4
0.32	0.3	0.4	0.3	0.4
0.31	0.3	0.3	0.3	0.3
0.3	0.3	0.3	0.3	0.3
0.29	0.28	0.31	0.28	0.32
0.28	0.27	0.3	0.27	0.3
0.27	0.26	0.28	0.26	0.29
0.26	0.25	0.27	0.25	0.28
0.25	0.24	0.26	0.24	0.27
0.24	0.23	0.25	0.23	0.25

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	32.74	INF	40.82	INF	37.45	INF
10	7.69	14.32	8.06	22.85	7.92	81.02
6	5.09	7.31	5.25	9	5.19	12.48
4	3.58	4.53	3.66	5.12	3.63	6.06
3	2.76	3.28	2.81	3.58	2.79	4.01
2.5	2.33	2.69	2.36	2.88	2.35	3.15
2	1.89	2.12	1.91	2.23	1.91	2.39
1.8	1.72	1.89	1.73	1.98	1.72	2.1
1.6	1.53	1.67	1.55	1.74	1.54	1.83
1.4	1.35	1.45	1.36	1.5	1.36	1.57
1.3	1.26	1.35	1.26	1.39	1.26	1.44
1.2	1.16	1.24	1.17	1.27	1.17	1.32
1.1	1.07	1.13	1.08	1.16	1.07	1.2
1	0.98	1.03	0.98	1.05	0.98	1.08
0.95	0.93	0.97	0.93	0.99	0.93	1.02
0.9	0.88	0.92	0.88	0.94	0.88	0.96
0.85	0.83	0.87	0.84	0.88	0.83	0.9
0.8	0.78	0.82	0.79	0.83	0.79	0.85
0.75	0.74	0.76	0.74	0.78	0.74	0.79
0.7	0.69	0.71	0.69	0.72	0.69	0.73
0.65	0.64	0.66	0.64	0.67	0.64	0.68
0.6	0.59	0.61	0.59	0.61	0.59	0.62
0.58	0.57	0.59	0.57	0.59	0.57	0.6
0.56	0.55	0.57	0.55	0.57	0.55	0.58
0.54	0.53	0.55	0.54	0.55	0.53	0.56
0.52	0.51	0.53	0.52	0.53	0.51	0.54
0.5	0.49	0.51	0.5	0.51	0.5	0.51
0.49	0.49	0.49	0.49	0.5	0.49	0.5
0.48	0.48	0.48	0.48	0.49	0.48	0.49
0.47	0.47	0.47	0.47	0.48	0.47	0.48
0.46	0.46	0.46	0.46	0.47	0.46	0.47
0.45	0.45	0.45	0.45	0.46	0.45	0.46
0.44	0.44	0.44	0.44	0.45	0.44	0.45
0.43	0.43	0.43	0.43	0.44	0.43	0.44
0.42	0.42	0.42	0.42	0.43	0.42	0.43
0.41	0.41	0.41	0.41	0.42	0.41	0.42
0.4	0.4	0.4	0.4	0.41	0.4	0.41
0.39	0.39	0.39	0.39	0.39	0.39	0.4
0.38	0.38	0.38	0.38	0.38	0.38	0.39
0.37	0.37	0.37	0.37	0.37	0.37	0.38
0.36	0.36	0.36	0.36	0.36	0.36	0.37
0.35	0.35	0.35	0.35	0.35	0.35	0.36
0.34	0.34	0.34	0.34	0.34	0.34	0.35
0.33	0.33	0.33	0.33	0.33	0.33	0.33
0.32	0.32	0.32	0.32	0.32	0.32	0.32
0.31	0.31	0.31	0.31	0.31	0.31	0.31
0.3	0.3	0.3	0.3	0.3	0.3	0.3

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	25.17	INF	15.08	INF	9.07	INF
10	7.19	INF	6.05	INF	4.8	INF
6	4.87	21.85	4.33	INF	3.65	INF
4	3.47	7.63	3.19	10.99	2.81	24.69
3	2.7	4.62	2.53	5.65	2.29	7.86
2.5	2.29	3.51	2.17	4.07	1.99	5.08
2	1.86	2.58	1.78	2.87	1.66	3.32
1.8	1.69	2.25	1.62	2.46	1.53	2.79
1.6	1.51	1.94	1.46	2.09	1.38	2.32
1.4	1.33	1.65	1.29	1.76	1.23	1.91
1.3	1.24	1.51	1.21	1.6	1.16	1.72
1.2	1.15	1.37	1.12	1.44	1.08	1.54
1.1	1.06	1.24	1.04	1.3	1	1.38
1	0.97	1.11	0.95	1.16	0.92	1.22
0.95	0.92	1.05	0.9	1.09	0.87	1.14
0.9	0.87	0.99	0.86	1.02	0.83	1.07
0.85	0.83	0.93	0.81	0.96	0.79	1
0.8	0.78	0.87	0.77	0.89	0.75	0.93
0.75	0.73	0.81	0.72	0.83	0.7	0.86
0.7	0.69	0.75	0.68	0.77	0.66	0.79
0.65	0.64	0.69	0.63	0.71	0.62	0.72
0.6	0.59	0.63	0.58	0.65	0.57	0.66
0.58	0.57	0.61	0.56	0.62	0.55	0.64
0.56	0.55	0.59	0.55	0.6	0.54	0.61
0.54	0.53	0.57	0.53	0.57	0.52	0.59
0.52	0.51	0.54	0.51	0.55	0.5	0.56
0.5	0.49	0.52	0.49	0.53	0.48	0.54
0.49	0.48	0.51	0.48	0.52	0.47	0.53
0.48	0.47	0.5	0.47	0.51	0.46	0.51
0.47	0.46	0.49	0.46	0.49	0.45	0.5
0.46	0.45	0.48	0.45	0.48	0.45	0.49
0.45	0.44	0.47	0.44	0.47	0.44	0.48
0.44	0.44	0.45	0.43	0.46	0.43	0.47
0.43	0.43	0.44	0.42	0.45	0.42	0.46
0.42	0.42	0.43	0.41	0.44	0.41	0.44
0.41	0.41	0.42	0.4	0.43	0.4	0.43
0.4	0.4	0.41	0.39	0.42	0.39	0.42
0.39	0.39	0.4	0.38	0.4	0.38	0.41
0.38	0.38	0.39	0.37	0.39	0.37	0.4
0.37	0.37	0.38	0.36	0.38	0.36	0.39
0.36	0.36	0.37	0.36	0.37	0.35	0.38
0.35	0.35	0.36	0.35	0.36	0.34	0.36
0.34	0.34	0.35	0.34	0.35	0.33	0.35
0.33	0.33	0.34	0.33	0.34	0.32	0.34
0.32	0.32	0.33	0.32	0.33	0.31	0.33
0.31	0.31	0.32	0.31	0.32	0.3	0.32
0.3	0.3	0.3	0.3	0.31	0.3	0.31

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	5.73	INF	3.77	INF
10	3.69	INF	2.78	INF
6	2.98	INF	2.36	INF
4	2.4	INF	1.99	INF
3	2.01	16.98	1.72	INF
2.5	1.78	7.74	1.55	29.88
2	1.52	4.26	1.35	7.1
1.8	1.4	3.41	1.26	4.99
1.6	1.28	2.73	1.16	3.64
1.4	1.15	2.17	1.06	2.7
1.3	1.09	1.93	1	2.33
1.2	1.02	1.71	0.94	2.01
1.1	0.95	1.5	0.88	1.73
1	0.87	1.31	0.82	1.48
0.95	0.84	1.22	0.79	1.36
0.9	0.8	1.14	0.75	1.26
0.85	0.76	1.06	0.72	1.16
0.8	0.72	0.98	0.69	1.06
0.75	0.68	0.9	0.65	0.97
0.7	0.64	0.83	0.61	0.88
0.65	0.6	0.75	0.58	0.8
0.6	0.56	0.68	0.54	0.72
0.58	0.54	0.66	0.52	0.69
0.56	0.52	0.63	0.51	0.66
0.54	0.51	0.6	0.49	0.63
0.52	0.49	0.58	0.48	0.6
0.5	0.47	0.55	0.46	0.57
0.49	0.46	0.54	0.45	0.56
0.48	0.46	0.53	0.44	0.55
0.47	0.45	0.51	0.44	0.53
0.46	0.44	0.5	0.43	0.52
0.45	0.43	0.49	0.42	0.5
0.44	0.42	0.48	0.41	0.49
0.43	0.41	0.46	0.4	0.48
0.42	0.4	0.45	0.39	0.47
0.41	0.39	0.44	0.39	0.45
0.4	0.38	0.43	0.38	0.44
0.39	0.38	0.42	0.37	0.43
0.38	0.37	0.4	0.36	0.41
0.37	0.36	0.39	0.35	0.4
0.36	0.35	0.38	0.34	0.39
0.35	0.34	0.37	0.33	0.38
0.34	0.33	0.36	0.32	0.36
0.33	0.32	0.35	0.32	0.35
0.32	0.31	0.33	0.31	0.34
0.31	0.3	0.32	0.3	0.33
0.3	0.29	0.31	0.29	0.32

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	106.47	INF	44.56	INF	22.36	INF
20	16.84	INF	13.82	INF	10.59	INF
10	9.14	36.05	8.18	INF	6.93	INF
7	6.57	14.06	6.06	20.02	5.35	41.96
5	4.78	7.75	4.5	9.26	4.1	12.18
4	3.86	5.57	3.68	6.3	3.41	7.51
3.5	3.39	4.64	3.25	5.13	3.04	5.9
3	2.92	3.79	2.82	4.11	2.66	4.59
2.5	2.44	3.02	2.37	3.21	2.26	3.5
2.2	2.16	2.59	2.1	2.73	2.01	2.93
2	1.96	2.31	1.92	2.42	1.84	2.58
1.8	1.77	2.05	1.73	2.13	1.67	2.25
1.6	1.58	1.79	1.55	1.85	1.5	1.94
1.5	1.48	1.66	1.45	1.72	1.41	1.79
1.4	1.38	1.54	1.36	1.59	1.32	1.65
1.3	1.28	1.42	1.27	1.46	1.23	1.51
1.2	1.19	1.3	1.17	1.33	1.14	1.37
1.1	1.09	1.18	1.08	1.21	1.05	1.24
1	0.99	1.07	0.98	1.09	0.96	1.11
0.95	0.94	1.01	0.93	1.03	0.92	1.05
0.9	0.89	0.95	0.88	0.97	0.87	0.99
0.85	0.84	0.9	0.84	0.91	0.82	0.93
0.8	0.79	0.84	0.79	0.85	0.78	0.87
0.78	0.77	0.82	0.77	0.83	0.76	0.84
0.76	0.75	0.79	0.75	0.81	0.74	0.82
0.74	0.74	0.77	0.73	0.78	0.72	0.8
0.72	0.72	0.75	0.71	0.76	0.7	0.77
0.7	0.7	0.73	0.69	0.74	0.68	0.75
0.68	0.68	0.71	0.67	0.72	0.66	0.73
0.66	0.66	0.68	0.65	0.69	0.64	0.7
0.64	0.64	0.66	0.63	0.67	0.63	0.68
0.62	0.62	0.64	0.61	0.65	0.61	0.66
0.6	0.6	0.62	0.59	0.63	0.59	0.63
0.59	0.59	0.61	0.58	0.62	0.58	0.62
0.58	0.58	0.6	0.57	0.6	0.57	0.61
0.57	0.57	0.59	0.56	0.59	0.56	0.6
0.56	0.56	0.58	0.55	0.58	0.55	0.59
0.55	0.55	0.57	0.54	0.57	0.54	0.58
0.54	0.54	0.56	0.53	0.56	0.53	0.57
0.53	0.53	0.54	0.52	0.55	0.52	0.56
0.52	0.52	0.53	0.52	0.54	0.51	0.54
0.51	0.51	0.52	0.51	0.53	0.5	0.53
0.5	0.5	0.51	0.5	0.52	0.49	0.52
0.49	0.49	0.5	0.49	0.51	0.48	0.51
0.48	0.48	0.49	0.48	0.5	0.47	0.5
0.47	0.47	0.48	0.47	0.48	0.46	0.49
0.46	0.46	0.47	0.46	0.47	0.45	0.48
0.45	0.45	0.46	0.45	0.46	0.44	0.47

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	12.90	INF	8.02	INF
20	7.87	INF	5.75	INF
10	5.66	INF	4.48	INF
7	4.57	INF	3.77	INF
5	3.63	21.36	3.11	INF
4	3.08	10.2	2.7	20.26
3.5	2.77	7.43	2.47	11.59
3	2.45	5.45	2.21	7.38
2.5	2.11	3.97	1.93	4.9
2.2	1.9	3.25	1.75	3.84
2	1.75	2.82	1.62	3.25
1.8	1.59	2.43	1.49	2.74
1.6	1.44	2.07	1.35	2.29
1.5	1.36	1.9	1.28	2.09
1.4	1.27	1.74	1.21	1.89
1.3	1.19	1.59	1.14	1.71
1.2	1.11	1.44	1.06	1.53
1.1	1.02	1.29	0.98	1.37
1	0.94	1.15	0.9	1.21
0.95	0.89	1.09	0.86	1.14
0.9	0.85	1.02	0.82	1.07
0.85	0.81	0.95	0.78	0.99
0.8	0.76	0.89	0.74	0.92
0.78	0.74	0.87	0.72	0.9
0.76	0.72	0.84	0.71	0.87
0.74	0.71	0.82	0.69	0.84
0.72	0.69	0.79	0.67	0.82
0.7	0.67	0.77	0.65	0.79
0.68	0.65	0.74	0.64	0.76
0.66	0.63	0.72	0.62	0.74
0.64	0.62	0.69	0.6	0.71
0.62	0.6	0.67	0.58	0.69
0.6	0.58	0.65	0.57	0.66
0.59	0.57	0.63	0.56	0.65
0.58	0.56	0.62	0.55	0.64
0.57	0.55	0.61	0.54	0.62
0.56	0.54	0.6	0.53	0.61
0.55	0.53	0.59	0.52	0.6
0.54	0.52	0.57	0.51	0.59
0.53	0.51	0.56	0.51	0.57
0.52	0.5	0.55	0.5	0.56
0.51	0.5	0.54	0.49	0.55
0.5	0.49	0.53	0.48	0.54
0.49	0.48	0.52	0.47	0.53
0.48	0.47	0.51	0.46	0.51
0.47	0.46	0.49	0.45	0.5
0.46	0.45	0.48	0.44	0.49
0.45	0.44	0.47	0.43	0.48

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	182.44	INF	169.21	INF	140.77	INF
50	39.28	68.82	38.62	90.49	36.92	INF
20	18.04	22.44	17.9	24.33	17.53	27.73
15	13.87	16.33	13.79	17.3	13.57	18.95
12	11.27	12.83	11.22	13.42	11.07	14.39
10	9.49	10.57	9.45	10.96	9.35	11.6
8	7.67	8.36	7.65	8.6	7.58	8.99
7	6.75	7.27	6.73	7.45	6.67	7.74
6	5.81	6.2	5.8	6.33	5.76	6.53
5.5	5.34	5.67	5.33	5.77	5.3	5.94
5	4.87	5.14	4.86	5.22	4.83	5.36
4.5	4.4	4.61	4.39	4.68	4.36	4.79
4	3.92	4.09	3.91	4.14	3.89	4.23
3.8	3.73	3.88	3.72	3.93	3.7	4
3.6	3.53	3.67	3.53	3.71	3.51	3.78
3.4	3.34	3.46	3.34	3.5	3.32	3.56
3.2	3.15	3.25	3.14	3.29	3.13	3.34
3	2.95	3.05	2.95	3.08	2.94	3.12
2.8	2.76	2.84	2.76	2.87	2.75	2.91
2.6	2.57	2.63	2.56	2.66	2.56	2.69
2.4	2.37	2.43	2.37	2.45	2.36	2.48
2.2	2.18	2.22	2.17	2.24	2.17	2.26
2	1.98	2.02	1.98	2.03	1.97	2.05
1.9	1.88	1.92	1.88	1.93	1.88	1.95
1.8	1.78	1.82	1.78	1.83	1.78	1.84
1.7	1.69	1.71	1.68	1.72	1.68	1.74
1.6	1.59	1.61	1.59	1.62	1.58	1.63
1.5	1.49	1.51	1.49	1.52	1.49	1.53
1.4	1.39	1.41	1.39	1.42	1.39	1.42
1.3	1.29	1.31	1.29	1.31	1.29	1.32
1.2	1.19	1.21	1.19	1.21	1.19	1.22
1.1	1.09	1.11	1.09	1.11	1.09	1.11
1	1	1	1	1.01	0.99	1.01

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	98.68	INF	64.40	INF	41.62	INF
50	33.22	INF	28.18	INF	22.75	INF
20	16.65	33.03	15.29	43.08	13.54	70.9
15	13.04	21.27	12.19	25.02	11.06	32.37
12	10.71	15.69	10.13	17.63	9.34	20.97
10	9.09	12.42	8.67	13.61	8.09	15.51
8	7.41	9.47	7.13	10.14	6.73	11.15
7	6.54	8.09	6.33	8.58	6.01	9.29
6	5.66	6.78	5.5	7.11	5.26	7.6
5.5	5.22	6.15	5.08	6.42	4.87	6.81
5	4.77	5.53	4.65	5.74	4.48	6.05
4.5	4.31	4.92	4.22	5.09	4.08	5.33
4	3.85	4.33	3.77	4.46	3.66	4.64
3.8	3.66	4.09	3.6	4.21	3.49	4.37
3.6	3.48	3.86	3.42	3.96	3.33	4.1
3.4	3.29	3.63	3.24	3.72	3.15	3.85
3.2	3.1	3.4	3.06	3.48	2.98	3.59
3	2.92	3.18	2.87	3.24	2.81	3.34
2.8	2.73	2.95	2.69	3.01	2.63	3.09
2.6	2.54	2.73	2.5	2.78	2.46	2.85
2.4	2.35	2.51	2.32	2.55	2.28	2.61
2.2	2.16	2.29	2.13	2.32	2.1	2.37
2	1.96	2.07	1.94	2.1	1.92	2.14
1.9	1.87	1.97	1.85	1.99	1.82	2.02
1.8	1.77	1.86	1.76	1.88	1.73	1.91
1.7	1.67	1.75	1.66	1.77	1.64	1.8
1.6	1.58	1.65	1.56	1.66	1.55	1.68
1.5	1.48	1.54	1.47	1.55	1.45	1.57
1.4	1.38	1.43	1.37	1.45	1.36	1.46
1.3	1.29	1.33	1.28	1.34	1.27	1.35
1.2	1.19	1.22	1.18	1.23	1.17	1.24
1.1	1.09	1.12	1.08	1.13	1.08	1.14
1	0.99	1.02	0.99	1.02	0.98	1.03

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	27.58	INF	18.59	INF
50	17.81	INF	13.58	INF
20	11.63	INF	9.68	INF
15	9.75	54.72	8.34	INF
12	8.4	28.48	7.33	56.9
10	7.37	19.25	6.54	29.02
8	6.23	12.95	5.63	16.72
7	5.61	10.5	5.12	12.84
6	4.95	8.38	4.57	9.8
5.5	4.61	7.43	4.28	8.52
5	4.26	6.54	3.97	7.36
4.5	3.89	5.7	3.65	6.32
4	3.51	4.92	3.32	5.36
3.8	3.36	4.61	3.18	5
3.6	3.2	4.32	3.04	4.66
3.4	3.04	4.03	2.9	4.33
3.2	2.88	3.75	2.75	4
3	2.72	3.48	2.6	3.69
2.8	2.56	3.21	2.45	3.39
2.6	2.39	2.95	2.3	3.1
2.4	2.22	2.69	2.14	2.81
2.2	2.05	2.44	1.98	2.54
2	1.88	2.19	1.82	2.27
1.9	1.79	2.07	1.74	2.14
1.8	1.7	1.95	1.66	2.02
1.7	1.61	1.83	1.57	1.89
1.6	1.52	1.72	1.49	1.76
1.5	1.43	1.6	1.4	1.64
1.4	1.34	1.49	1.31	1.52
1.3	1.25	1.37	1.23	1.4
1.2	1.16	1.26	1.14	1.29
1.1	1.06	1.15	1.05	1.17
1	0.97	1.04	0.96	1.06

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	239.71	INF	237.25	INF	164.57	INF
100	70.62	INF	70.39	INF	62.26	INF
90	65.48	INF	65.29	INF	58.23	INF
80	60.03	INF	59.87	INF	53.88	INF
70	54.22	98.79	54.09	INF	49.16	INF
60	48.03	79.96	47.92	INF	44.01	INF
50	41.41	63.12	41.33	76.46	38.39	98.32
45	37.92	55.35	37.85	65.33	35.37	80.65
40	34.31	47.97	34.26	55.28	32.21	65.85
35	30.57	40.95	30.52	46.15	28.89	53.29
30	26.69	34.26	26.65	37.82	25.4	42.48
25	22.66	27.88	22.64	30.19	21.73	33.08
20	18.48	21.8	18.46	23.18	17.85	24.84
15	14.13	15.99	14.12	16.71	13.76	17.55
14	13.24	14.85	13.23	15.48	12.92	16.2
13	12.34	13.73	12.34	14.26	12.06	14.87
12	11.44	12.62	11.43	13.07	11.2	13.57
11	10.53	11.52	10.52	11.89	10.32	12.3
10	9.61	10.43	9.6	10.73	9.44	11.06
9.5	9.15	9.88	9.14	10.15	8.99	10.45
9	8.68	9.34	8.68	9.58	8.54	9.85
8.5	8.22	8.8	8.21	9.02	8.09	9.25
8	7.75	8.27	7.75	8.45	7.64	8.66
7.5	7.28	7.73	7.28	7.9	7.18	8.08
7	6.81	7.2	6.81	7.34	6.72	7.5
6.5	6.33	6.67	6.33	6.79	6.26	6.93
6	5.86	6.15	5.86	6.25	5.8	6.36
5.5	5.38	5.62	5.38	5.71	5.33	5.8
5	4.9	5.1	4.9	5.17	4.86	5.24
4.8	4.71	4.89	4.71	4.96	4.67	5.02
4.6	4.52	4.69	4.52	4.74	4.48	4.8
4.5	4.42	4.58	4.42	4.64	4.39	4.7
4.4	4.32	4.48	4.32	4.53	4.29	4.59
4.2	4.13	4.27	4.13	4.32	4.1	4.37
4	3.94	4.06	3.94	4.11	3.91	4.15
3.8	3.74	3.86	3.74	3.9	3.72	3.94
3.6	3.55	3.65	3.55	3.68	3.53	3.72
3.5	3.45	3.55	3.45	3.58	3.43	3.61
3.4	3.36	3.45	3.36	3.48	3.34	3.51
3.2	3.16	3.24	3.16	3.27	3.14	3.29
3	2.97	3.04	2.97	3.06	2.95	3.08
2.9	2.87	2.93	2.87	2.95	2.85	2.98
2.8	2.77	2.83	2.77	2.85	2.76	2.87
2.7	2.67	2.73	2.67	2.75	2.66	2.77
2.6	2.57	2.63	2.57	2.64	2.56	2.66

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
2.5	2.48	2.52	2.48	2.54	2.47	2.56
2.4	2.38	2.42	2.38	2.44	2.37	2.45
2.3	2.28	2.32	2.28	2.33	2.27	2.35
2.2	2.18	2.22	2.18	2.23	2.17	2.24
2.1	2.08	2.12	2.08	2.13	2.08	2.14
2	1.99	2.01	1.99	2.02	1.98	2.03
1.95	1.94	1.96	1.94	1.97	1.93	1.98
1.9	1.89	1.91	1.89	1.92	1.88	1.93
1.85	1.84	1.86	1.84	1.87	1.83	1.88
1.8	1.79	1.81	1.79	1.82	1.78	1.83
1.75	1.74	1.76	1.74	1.77	1.73	1.78
1.7	1.69	1.71	1.69	1.72	1.68	1.72
1.65	1.64	1.66	1.64	1.67	1.64	1.67
1.6	1.59	1.61	1.59	1.61	1.59	1.62
1.55	1.54	1.56	1.54	1.56	1.54	1.57
1.5	1.49	1.51	1.49	1.51	1.49	1.52
1.45	1.44	1.46	1.44	1.46	1.44	1.47
1.4	1.39	1.41	1.39	1.41	1.39	1.42
1.35	1.34	1.36	1.34	1.36	1.34	1.36
1.3	1.29	1.31	1.29	1.31	1.29	1.31
1.25	1.24	1.26	1.24	1.26	1.24	1.26
1.2	1.2	1.2	1.2	1.21	1.19	1.21
1.15	1.15	1.15	1.15	1.16	1.14	1.16
1.1	1.1	1.1	1.1	1.11	1.09	1.11
1.05	1.05	1.05	1.05	1.06	1.04	1.06
1	1	1	1	1	1	1.01
0.98	0.98	0.98	0.98	0.98	0.98	0.99
0.96	0.96	0.96	0.96	0.96	0.96	0.97
0.95	0.95	0.95	0.95	0.95	0.95	0.96
0.94	0.94	0.94	0.94	0.94	0.94	0.95
0.92	0.92	0.92	0.92	0.92	0.92	0.93
0.9	0.9	0.9	0.9	0.9	0.9	0.91
0.88	0.88	0.88	0.88	0.88	0.88	0.89
0.86	0.86	0.86	0.86	0.86	0.86	0.86
0.85	0.85	0.85	0.85	0.85	0.85	0.85
0.84	0.84	0.84	0.84	0.84	0.84	0.84
0.82	0.82	0.82	0.82	0.82	0.82	0.82
0.8	0.8	0.8	0.8	0.8	0.8	0.8
0.78	0.78	0.78	0.78	0.78	0.78	0.78
0.76	0.76	0.76	0.76	0.76	0.76	0.76
0.75	0.75	0.75	0.75	0.75	0.75	0.75
0.74	0.74	0.74	0.74	0.74	0.74	0.74
0.72	0.72	0.72	0.72	0.72	0.72	0.72
0.7	0.7	0.7	0.7	0.7	0.7	0.7

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	112.38	INF	76.42	INF	51.79	INF
100	52.97	INF	43.37	INF	34.17	INF
90	50.03	INF	41.39	INF	32.93	INF
80	46.79	INF	39.14	INF	31.5	INF
70	43.19	INF	36.59	INF	29.83	INF
60	39.17	INF	33.67	INF	27.86	INF
50	34.65	INF	30.28	INF	25.5	INF
45	32.18	INF	28.38	INF	24.14	INF
40	29.54	88.37	26.31	INF	22.63	INF
35	26.73	67.11	24.06	INF	20.94	INF
30	23.72	50.81	21.59	69.23	19.05	INF
25	20.48	37.92	18.88	47.29	16.91	71.06
20	17.01	27.46	15.89	32.05	14.48	41.42
15	13.26	18.82	12.57	20.85	11.67	24.43
14	12.47	17.26	11.86	18.96	11.06	21.87
13	11.67	15.76	11.14	17.16	10.43	19.51
12	10.86	14.31	10.4	15.45	9.78	17.32
11	10.04	12.91	9.64	13.83	9.11	15.3
10	9.2	11.55	8.87	12.27	8.41	13.42
9.5	8.78	10.88	8.47	11.53	8.06	12.53
9	8.35	10.23	8.07	10.79	7.7	11.67
8.5	7.92	9.59	7.67	10.08	7.33	10.84
8	7.48	8.95	7.26	9.38	6.96	10.03
7.5	7.04	8.33	6.85	8.7	6.58	9.25
7	6.6	7.71	6.43	8.03	6.19	8.5
6.5	6.16	7.11	6.01	7.37	5.8	7.77
6	5.71	6.51	5.58	6.73	5.4	7.06
5.5	5.25	5.93	5.15	6.11	4.99	6.37
5	4.8	5.35	4.71	5.49	4.58	5.71
4.8	4.61	5.12	4.53	5.25	4.41	5.45
4.6	4.43	4.89	4.35	5.01	4.24	5.19
4.5	4.34	4.78	4.26	4.89	4.16	5.06
4.4	4.24	4.66	4.17	4.77	4.07	4.93
4.2	4.06	4.44	3.99	4.54	3.9	4.68
4	3.87	4.22	3.81	4.31	3.73	4.43
3.8	3.68	3.99	3.63	4.07	3.56	4.19
3.6	3.5	3.77	3.45	3.84	3.38	3.94
3.5	3.4	3.66	3.36	3.73	3.29	3.82
3.4	3.31	3.55	3.26	3.61	3.2	3.7
3.2	3.12	3.33	3.08	3.39	3.03	3.47
3	2.93	3.12	2.9	3.16	2.85	3.23
2.9	2.83	3.01	2.8	3.05	2.76	3.11
2.8	2.74	2.9	2.71	2.94	2.67	3
2.7	2.64	2.79	2.62	2.83	2.58	2.88
2.6	2.55	2.69	2.52	2.72	2.49	2.77

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
2.5	2.45	2.58	2.43	2.61	2.40	2.65
2.4	2.35	2.47	2.33	2.5	2.3	2.54
2.3	2.26	2.37	2.24	2.39	2.21	2.43
2.2	2.16	2.26	2.14	2.28	2.12	2.32
2.1	2.07	2.15	2.05	2.18	2.03	2.21
2	1.97	2.05	1.95	2.07	1.93	2.09
1.95	1.92	2	1.91	2.01	1.89	2.04
1.9	1.87	1.94	1.86	1.96	1.84	1.98
1.85	1.82	1.89	1.81	1.91	1.79	1.93
1.8	1.78	1.84	1.76	1.85	1.75	1.87
1.75	1.73	1.79	1.72	1.8	1.7	1.82
1.7	1.68	1.73	1.67	1.75	1.65	1.77
1.65	1.63	1.68	1.62	1.69	1.61	1.71
1.6	1.58	1.63	1.57	1.64	1.56	1.66
1.55	1.53	1.58	1.52	1.59	1.51	1.6
1.5	1.48	1.53	1.48	1.54	1.46	1.55
1.45	1.43	1.47	1.43	1.48	1.42	1.5
1.4	1.39	1.42	1.38	1.43	1.37	1.44
1.35	1.34	1.37	1.33	1.38	1.32	1.39
1.3	1.29	1.32	1.28	1.33	1.27	1.34
1.25	1.24	1.27	1.23	1.27	1.23	1.28
1.2	1.19	1.22	1.19	1.22	1.18	1.23
1.15	1.14	1.16	1.14	1.17	1.13	1.18
1.1	1.09	1.11	1.09	1.12	1.08	1.12
1.05	1.04	1.06	1.04	1.07	1.03	1.07
1	0.99	1.01	0.99	1.01	0.99	1.02
0.98	0.97	0.99	0.97	0.99	0.97	1
0.96	0.95	0.97	0.95	0.97	0.95	0.98
0.95	0.94	0.96	0.94	0.96	0.94	0.97
0.94	0.93	0.95	0.93	0.95	0.93	0.96
0.92	0.91	0.93	0.91	0.93	0.91	0.94
0.9	0.89	0.91	0.89	0.91	0.89	0.91
0.88	0.88	0.89	0.87	0.89	0.87	0.89
0.86	0.86	0.87	0.85	0.87	0.85	0.87
0.85	0.85	0.86	0.84	0.86	0.84	0.86
0.84	0.84	0.85	0.83	0.85	0.83	0.85
0.82	0.82	0.83	0.81	0.83	0.81	0.83
0.8	0.8	0.81	0.79	0.81	0.79	0.81
0.78	0.78	0.79	0.77	0.79	0.77	0.79
0.76	0.76	0.77	0.75	0.77	0.75	0.77
0.75	0.75	0.75	0.75	0.76	0.74	0.76
0.74	0.74	0.74	0.74	0.75	0.73	0.75
0.72	0.72	0.72	0.72	0.73	0.71	0.73
0.7	0.7	0.7	0.7	0.71	0.69	0.71

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	35.14	INF	24.08	INF
100	26.05	INF	19.44	INF
90	25.32	INF	19.04	INF
80	24.47	INF	18.55	INF
70	23.45	INF	17.96	INF
60	22.22	INF	17.23	INF
50	20.7	INF	16.31	INF
45	19.79	INF	15.74	INF
40	18.77	INF	15.09	INF
35	17.6	INF	14.33	INF
30	16.25	INF	13.42	INF
25	14.67	INF	12.33	INF
20	12.8	68.85	10.99	INF
15	10.56	31.89	9.3	55.7
14	10.06	27.65	8.91	43.9
13	9.54	23.97	8.5	35.27
12	8.99	20.75	8.06	28.7
11	8.42	17.91	7.61	23.52
10	7.83	15.38	7.12	19.33
9.5	7.52	14.22	6.86	17.52
9	7.21	13.12	6.6	15.87
8.5	6.88	12.07	6.33	14.36
8	6.55	11.08	6.05	12.97
7.5	6.22	10.13	5.76	11.69
7	5.87	9.23	5.47	10.51
6.5	5.52	8.37	5.16	9.41
6	5.16	7.56	4.84	8.38
5.5	4.78	6.77	4.52	7.43
5	4.4	6.02	4.18	6.53
4.8	4.25	5.73	4.04	6.19
4.6	4.09	5.45	3.9	5.86
4.5	4.01	5.31	3.83	5.69
4.4	3.94	5.17	3.75	5.53
4.2	3.78	4.89	3.61	5.22
4	3.61	4.62	3.46	4.91
3.8	3.45	4.35	3.31	4.61
3.6	3.29	4.09	3.16	4.31
3.5	3.2	3.96	3.08	4.17
3.4	3.12	3.83	3.01	4.02
3.2	2.95	3.58	2.85	3.74
3	2.78	3.33	2.69	3.47
2.9	2.7	3.2	2.61	3.33
2.8	2.61	3.08	2.53	3.2
2.7	2.52	2.96	2.45	3.07
2.6	2.44	2.84	2.37	2.94

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
2.5	2.35	2.72	2.29	2.81
2.4	2.26	2.6	2.2	2.68
2.3	2.17	2.48	2.12	2.56
2.2	2.08	2.36	2.04	2.43
2.1	1.99	2.25	1.95	2.31
2	1.91	2.13	1.86	2.19
1.95	1.86	2.07	1.82	2.13
1.9	1.81	2.02	1.78	2.07
1.85	1.77	1.96	1.74	2.01
1.8	1.72	1.9	1.69	1.95
1.75	1.68	1.85	1.65	1.89
1.7	1.63	1.79	1.6	1.83
1.65	1.59	1.74	1.56	1.77
1.6	1.54	1.68	1.52	1.71
1.55	1.49	1.62	1.47	1.65
1.5	1.45	1.57	1.43	1.6
1.45	1.4	1.51	1.38	1.54
1.4	1.36	1.46	1.34	1.48
1.35	1.31	1.4	1.29	1.43
1.3	1.26	1.35	1.25	1.37
1.25	1.22	1.3	1.2	1.31
1.2	1.17	1.24	1.15	1.26
1.15	1.12	1.19	1.11	1.2
1.1	1.07	1.13	1.06	1.15
1.05	1.03	1.08	1.02	1.09
1	0.98	1.03	0.97	1.04
0.98	0.96	1.01	0.95	1.02
0.96	0.94	0.98	0.93	0.99
0.95	0.93	0.97	0.92	0.98
0.94	0.92	0.96	0.91	0.97
0.92	0.9	0.94	0.9	0.95
0.9	0.88	0.92	0.88	0.93
0.88	0.86	0.9	0.86	0.91
0.86	0.85	0.88	0.84	0.89
0.85	0.84	0.87	0.83	0.87
0.84	0.83	0.86	0.82	0.86
0.82	0.81	0.84	0.8	0.84
0.8	0.79	0.82	0.78	0.82
0.78	0.77	0.79	0.76	0.8
0.76	0.75	0.77	0.74	0.78
0.75	0.74	0.76	0.74	0.77
0.74	0.73	0.75	0.73	0.76
0.72	0.71	0.73	0.71	0.74
0.7	0.69	0.71	0.69	0.72

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	58.98	INF	33.71	INF	19.37	INF
10	8.56	28.62	7.73	75.8	6.62	INF
8	7.05	16.6	6.48	25.92	5.69	83.76
7	6.27	12.77	5.81	17.63	5.17	33.16
6	5.45	9.77	5.11	12.36	4.6	18.37
5	4.62	7.35	4.37	8.71	4	11.31
4	3.75	5.36	3.59	6.04	3.33	7.17
3	2.86	3.69	2.76	4	2.61	4.46
2.5	2.4	2.95	2.33	3.15	2.23	3.42
2	1.94	2.27	1.89	2.38	1.82	2.54
1.8	1.75	2.02	1.71	2.1	1.66	2.22
1.6	1.56	1.77	1.53	1.83	1.49	1.92
1.5	1.47	1.64	1.44	1.7	1.4	1.77
1.4	1.37	1.52	1.35	1.57	1.31	1.63
1.3	1.27	1.4	1.26	1.44	1.23	1.49
1.2	1.18	1.29	1.16	1.32	1.14	1.36
1.1	1.08	1.17	1.07	1.2	1.05	1.23
1	0.98	1.06	0.97	1.08	0.96	1.11
0.95	0.94	1	0.93	1.02	0.91	1.04
0.9	0.89	0.95	0.88	0.96	0.87	0.98
0.85	0.84	0.89	0.83	0.9	0.82	0.92
0.8	0.79	0.83	0.78	0.85	0.77	0.86
0.75	0.74	0.78	0.74	0.79	0.73	0.8
0.7	0.69	0.73	0.69	0.73	0.68	0.75
0.65	0.64	0.67	0.64	0.68	0.63	0.69
0.62	0.62	0.64	0.61	0.65	0.61	0.66
0.6	0.59	0.62	0.59	0.62	0.59	0.63
0.58	0.58	0.6	0.57	0.6	0.57	0.61
0.56	0.56	0.57	0.55	0.58	0.55	0.59
0.55	0.55	0.56	0.54	0.57	0.54	0.58
0.54	0.54	0.55	0.53	0.56	0.53	0.56
0.52	0.52	0.53	0.51	0.54	0.51	0.54

Schärfentieftabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	11.83	INF	7.56	INF
10	5.45	INF	4.34	INF
8	4.81	INF	3.93	INF
7	4.43	INF	3.67	INF
6	4.01	53.03	3.38	INF
5	3.54	18.85	3.05	INF
4	3.02	9.58	2.65	17.89
3	2.42	5.27	2.18	7.04
2.5	2.08	3.87	1.91	4.74
2	1.73	2.77	1.61	3.18
1.8	1.58	2.39	1.48	2.69
1.6	1.42	2.04	1.34	2.25
1.5	1.35	1.88	1.27	2.05
1.4	1.27	1.72	1.2	1.87
1.3	1.18	1.57	1.13	1.69
1.2	1.1	1.42	1.05	1.52
1.1	1.02	1.28	0.98	1.36
1	0.93	1.14	0.9	1.2
0.95	0.89	1.08	0.86	1.13
0.9	0.85	1.01	0.82	1.06
0.85	0.8	0.95	0.78	0.99
0.8	0.76	0.89	0.74	0.92
0.75	0.71	0.82	0.69	0.85
0.7	0.67	0.76	0.65	0.78
0.65	0.62	0.7	0.61	0.72
0.62	0.6	0.67	0.59	0.69
0.6	0.58	0.64	0.57	0.66
0.58	0.56	0.62	0.55	0.63
0.56	0.54	0.6	0.53	0.61
0.55	0.53	0.58	0.52	0.6
0.54	0.52	0.57	0.51	0.58
0.52	0.5	0.55	0.5	0.56

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.020 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
0.5	0.49	0.53	0.48	0.54
0.49	0.48	0.52	0.47	0.52
0.48	0.47	0.5	0.46	0.51
0.47	0.46	0.49	0.45	0.5
0.46	0.45	0.48	0.44	0.49
0.45	0.44	0.47	0.43	0.48
0.44	0.43	0.46	0.42	0.47
0.43	0.42	0.45	0.41	0.45
0.42	0.41	0.44	0.41	0.44
0.41	0.4	0.43	0.4	0.43
0.4	0.39	0.41	0.39	0.42
0.39	0.38	0.4	0.38	0.41
0.38	0.37	0.39	0.37	0.4
0.37	0.37	0.38	0.36	0.39
0.37	0.36	0.38	0.36	0.39
0.36	0.35	0.37	0.35	0.37
0.35	0.34	0.36	0.34	0.36
0.34	0.33	0.35	0.33	0.35
0.33	0.33	0.34	0.32	0.34
0.32	0.32	0.33	0.32	0.33
0.32	0.32	0.33	0.31	0.33
0.31	0.31	0.32	0.3	0.32
0.3	0.3	0.31	0.29	0.31
0.29	0.29	0.3	0.29	0.3
0.28	0.28	0.28	0.28	0.29
0.28	0.28	0.28	0.27	0.28
0.27	0.27	0.27	0.27	0.28
0.26	0.26	0.26	0.26	0.26
0.25	0.25	0.25	0.25	0.25
0.24	0.24	0.24	0.24	0.24
0.24	0.23	0.24	0.23	0.24

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 18/T3.6 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	3.6		4		5.6	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	3.95	INF	3.55	INF	3.59	INF
10	2.86	INF	2.65	INF	2.67	INF
6	2.42	INF	2.27	INF	2.28	INF
4	2.03	INF	1.92	INF	1.93	INF
3	1.74	12.22	1.67	11.43	1.67	INF
2.5	1.57	6.61	1.51	6.38	1.51	INF
2	1.36	3.92	1.32	3.83	1.32	24.15
1.8	1.27	3.20	1.23	3.14	1.23	9.87
1.6	1.17	2.60	1.14	2.56	1.14	5.68
1.4	1.06	2.09	1.04	2.07	1.04	3.67
1.3	1.01	1.87	0.98	1.85	0.98	3.02
1.2	0.95	1.66	0.93	1.65	0.93	2.5
1.1	0.89	1.47	0.87	1.46	0.87	2.08
1	0.82	1.29	0.81	1.28	0.81	1.73
0.95	0.79	1.21	0.78	1.2	0.78	1.57
0.9	0.76	1.12	0.74	1.12	0.74	1.43
0.85	0.72	1.04	0.71	1.04	0.71	1.3
0.8	0.69	0.97	0.68	0.96	0.68	1.18
0.75	0.65	0.89	0.64	0.89	0.64	1.07
0.7	0.61	0.82	0.61	0.82	0.61	0.96
0.65	0.58	0.75	0.57	0.75	0.57	0.86
0.6	0.54	0.68	0.53	0.68	0.53	0.77
0.58	0.52	0.66	0.52	0.65	0.52	0.74
0.56	0.51	0.63	0.5	0.63	0.5	0.7
0.54	0.49	0.6	0.49	0.6	0.49	0.67
0.52	0.47	0.58	0.47	0.58	0.47	0.64
0.5	0.46	0.55	0.45	0.55	0.45	0.61
0.48	0.44	0.53	0.44	0.53	0.44	0.57
0.46	0.43	0.5	0.42	0.5	0.42	0.54
0.44	0.41	0.48	0.41	0.48	0.41	0.52
0.42	0.39	0.45	0.39	0.45	0.39	0.49
0.4	0.38	0.43	0.37	0.43	0.37	0.46
0.39	0.37	0.42	0.36	0.42	0.36	0.44
0.38	0.36	0.41	0.36	0.4	0.36	0.43
0.37	0.35	0.39	0.35	0.39	0.35	0.42
0.36	0.34	0.38	0.34	0.38	0.34	0.4
0.35	0.33	0.37	0.33	0.37	0.33	0.39
0.34	0.32	0.36	0.32	0.36	0.32	0.38
0.33	0.31	0.35	0.31	0.35	0.31	0.36
0.32	0.31	0.34	0.3	0.34	0.3	0.35
0.31	0.3	0.32	0.3	0.32	0.3	0.34
0.3	0.29	0.31	0.29	0.31	0.29	0.33

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 18/T3.6 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	8		11		16	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	3.85	INF	2.70	INF	1.64	INF
10	2.81	INF	2.15	INF	1.43	INF
6	2.38	INF	1.90	INF	1.31	INF
4	2.00	INF	1.65	INF	1.19	INF
3	1.72	INF	1.46	INF	1.10	INF
2.5	1.55	INF	1.34	INF	1.03	INF
2	1.35	INF	1.19	INF	0.94	INF
1.8	1.26	INF	1.12	INF	0.90	INF
1.6	1.16	INF	1.04	INF	0.85	INF
1.4	1.06	INF	0.96	INF	0.79	INF
1.3	1.00	INF	0.91	INF	0.76	INF
1.2	0.94	13.35	0.86	INF	0.73	INF
1.1	0.88	6.22	0.81	INF	0.7	INF
1	0.82	3.79	0.76	INF	0.66	INF
0.95	0.79	3.09	0.73	INF	0.64	INF
0.9	0.75	2.57	0.7	15.24	0.62	INF
0.85	0.72	2.16	0.67	6.96	0.59	INF
0.8	0.68	1.83	0.64	4.33	0.57	INF
0.75	0.65	1.56	0.61	3.03	0.55	INF
0.7	0.61	1.34	0.58	2.25	0.52	12.61
0.65	0.57	1.15	0.55	1.74	0.5	4.6
0.6	0.54	0.98	0.51	1.38	0.47	2.64
0.58	0.52	0.92	0.5	1.26	0.46	2.22
0.56	0.5	0.87	0.48	1.15	0.45	1.89
0.54	0.49	0.82	0.47	1.06	0.43	1.64
0.52	0.47	0.77	0.46	0.97	0.42	1.43
0.5	0.46	0.72	0.44	0.89	0.41	1.26
0.48	0.44	0.67	0.43	0.82	0.4	1.11
0.46	0.42	0.63	0.41	0.76	0.38	0.99
0.44	0.41	0.59	0.4	0.69	0.37	0.88
0.42	0.39	0.55	0.38	0.64	0.36	0.79
0.4	0.37	0.51	0.36	0.59	0.34	0.71
0.39	0.37	0.49	0.36	0.56	0.34	0.67
0.38	0.36	0.48	0.35	0.54	0.33	0.63
0.37	0.35	0.46	0.34	0.51	0.32	0.6
0.36	0.34	0.44	0.33	0.49	0.32	0.57
0.35	0.33	0.43	0.32	0.47	0.31	0.54
0.34	0.32	0.41	0.32	0.45	0.3	0.51
0.33	0.31	0.39	0.31	0.43	0.29	0.48
0.32	0.31	0.38	0.3	0.41	0.29	0.46
0.31	0.3	0.36	0.29	0.39	0.28	0.43
0.3	0.29	0.35	0.28	0.37	0.27	0.41

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 18/T3.6 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.02	INF
10	0.94	INF
6	0.89	INF
4	0.84	INF
3	0.79	INF
2.5	0.76	INF
2	0.71	INF
1.8	0.69	INF
1.6	0.66	INF
1.4	0.63	INF
1.3	0.61	INF
1.2	0.59	INF
1.1	0.57	INF
1	0.54	INF
0.95	0.53	INF
0.9	0.52	INF
0.85	0.5	INF
0.8	0.49	INF
0.75	0.47	INF
0.7	0.45	INF
0.65	0.43	INF
0.6	0.41	INF
0.58	0.41	INF
0.56	0.4	15.35
0.54	0.39	6.48
0.52	0.38	4
0.5	0.37	2.83
0.48	0.36	2.15
0.46	0.35	1.71
0.44	0.34	1.39
0.42	0.33	1.16
0.4	0.32	0.98
0.39	0.31	0.91
0.38	0.31	0.84
0.37	0.3	0.78
0.36	0.3	0.72
0.35	0.29	0.67
0.34	0.28	0.63
0.33	0.28	0.58
0.32	0.27	0.54
0.31	0.26	0.51
0.3	0.26	0.47

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 21/T2.9 T*



Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	8		11		16	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	4.16	INF	2.82	INF	1.86	INF
10	2.98	INF	2.24	INF	1.60	INF
5	2.32	INF	1.85	INF	1.40	INF
3	1.79	INF	1.51	INF	1.20	INF
2	1.40	50.32	1.22	INF	1.02	INF
1.7	1.25	8.48	1.11	INF	0.94	INF
1.5	1.14	4.88	1.03	54.45	0.88	INF
1.3	1.03	3.14	0.94	7.31	0.82	INF
1.1	0.90	2.11	0.83	3.35	0.74	14.81
1	0.84	1.74	0.78	2.48	0.70	5.63
0.9	0.77	1.43	0.72	1.89	0.65	3.21
0.8	0.7	1.18	0.66	1.45	0.6	2.09
0.75	0.66	1.06	0.63	1.27	0.58	1.73
0.7	0.62	0.95	0.59	1.12	0.55	1.44
0.65	0.59	0.86	0.56	0.98	0.52	1.21
0.6	0.55	0.76	0.52	0.86	0.49	1.02
0.55	0.51	0.68	0.49	0.75	0.46	0.86
0.5	0.46	0.6	0.45	0.65	0.43	0.73
0.48	0.45	0.57	0.43	0.61	0.41	0.68
0.46	0.43	0.54	0.42	0.58	0.4	0.63
0.44	0.41	0.51	0.4	0.54	0.39	0.59
0.42	0.4	0.48	0.39	0.51	0.37	0.55
0.4	0.38	0.45	0.37	0.47	0.36	0.51
0.39	0.37	0.44	0.36	0.46	0.35	0.49
0.38	0.36	0.42	0.35	0.44	0.34	0.47
0.37	0.35	0.41	0.35	0.43	0.34	0.46
0.36	0.34	0.4	0.34	0.41	0.33	0.44
0.35	0.34	0.38	0.33	0.4	0.32	0.42
0.34	0.33	0.37	0.32	0.38	0.31	0.4
0.33	0.32	0.36	0.31	0.37	0.3	0.39
0.32	0.31	0.35	0.3	0.36	0.3	0.37
0.31	0.3	0.33	0.3	0.34	0.29	0.36
0.3	0.29	0.32	0.29	0.33	0.28	0.34
0.29	0.28	0.31	0.28	0.32	0.27	0.33
0.28	0.27	0.3	0.27	0.3	0.26	0.31
0.27	0.26	0.28	0.26	0.29	0.26	0.3
0.26	0.25	0.27	0.25	0.28	0.25	0.29
0.25	0.25	0.26	0.24	0.27	0.24	0.27
0.24	0.24	0.25	0.23	0.25	0.23	0.26

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 21/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.26	INF
10	1.14	INF
5	1.04	INF
3	0.93	INF
2	0.82	INF
1.7	0.77	INF
1.5	0.74	INF
1.3	0.69	INF
1.1	0.64	INF
1	0.61	INF
0.9	0.58	INF
0.8	0.54	5.73
0.75	0.52	3.55
0.7	0.5	2.48
0.65	0.48	1.84
0.6	0.45	1.42
0.55	0.43	1.11
0.5	0.4	0.89
0.48	0.39	0.81
0.46	0.38	0.74
0.44	0.37	0.68
0.42	0.35	0.62
0.4	0.34	0.57
0.39	0.33	0.55
0.38	0.33	0.52
0.37	0.32	0.5
0.36	0.31	0.48
0.35	0.31	0.46
0.34	0.3	0.44
0.33	0.29	0.42
0.32	0.29	0.4
0.31	0.28	0.38
0.3	0.27	0.36
0.29	0.26	0.34
0.28	0.26	0.33
0.27	0.25	0.31
0.26	0.24	0.3
0.25	0.23	0.28
0.24	0.23	0.27

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 25/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.52	INF
4	1.14	INF
2	0.91	INF
1.3	0.75	INF
1	0.65	4.86
0.8	0.57	2.00
0.7	0.52	1.41
0.6	0.47	1.02
0.55	0.44	0.86
0.5	0.41	0.73
0.45	0.38	0.61
0.4	0.35	0.51
0.38	0.33	0.48
0.36	0.32	0.44
0.34	0.3	0.41
0.32	0.29	0.38
0.3	0.27	0.34
0.29	0.27	0.33
0.28	0.26	0.32
0.27	0.25	0.3
0.26	0.24	0.29
0.25	0.24	0.27
0.24	0.23	0.26
0.23	0.22	0.25
0.22	0.21	0.23
0.21	0.2	0.22
0.2	0.19	0.21
0.19	0.18	0.2
0.18	0.18	0.19
0.17	0.17	0.17

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 28/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	10.34	INF	7.39	INF	4.74	INF
10	5.13	INF	4.29	INF	3.25	INF
5	3.41	INF	3.03	INF	2.48	INF
3	2.36	7.90	2.17	26.61	1.88	INF
2	1.70	3.33	1.60	4.67	1.44	8.95
1.6	1.41	2.32	1.34	2.89	1.23	4.06
1.4	1.25	1.91	1.2	2.27	1.11	2.92
1.2	1.09	1.55	1.05	1.77	0.99	2.12
1	0.93	1.22	0.9	1.35	0.85	1.54
0.9	0.84	1.07	0.82	1.16	0.78	1.3
0.8	0.75	0.93	0.74	0.99	0.71	1.09
0.75	0.71	0.86	0.7	0.91	0.67	0.99
0.7	0.67	0.79	0.65	0.84	0.63	0.9
0.65	0.62	0.73	0.61	0.76	0.59	0.81
0.6	0.6	0.7	0.6	0.7	0.6	0.7
0.55	0.5	0.6	0.5	0.6	0.5	0.7
0.5	0.5	0.5	0.5	0.6	0.5	0.6
0.48	0.5	0.5	0.5	0.5	0.5	0.6
0.46	0.45	0.49	0.44	0.51	0.43	0.52
0.44	0.43	0.47	0.42	0.48	0.42	0.5
0.42	0.41	0.44	0.41	0.46	0.4	0.47
0.4	0.39	0.42	0.39	0.43	0.38	0.44
0.39	0.38	0.41	0.38	0.42	0.37	0.43
0.38	0.37	0.4	0.37	0.41	0.36	0.42
0.37	0.36	0.39	0.36	0.39	0.35	0.4
0.36	0.35	0.38	0.35	0.38	0.35	0.39
0.35	0.34	0.36	0.34	0.37	0.34	0.38
0.34	0.33	0.35	0.33	0.36	0.33	0.37
0.33	0.3	0.3	0.3	0.4	0.3	0.4
0.32	0.3	0.3	0.3	0.3	0.3	0.3
0.31	0.3	0.3	0.3	0.3	0.3	0.3
0.3	0.3	0.3	0.3	0.3	0.3	0.3
0.29	0.29	0.3	0.28	0.3	0.28	0.31
0.28	0.28	0.29	0.28	0.29	0.27	0.29
0.27	0.27	0.28	0.27	0.28	0.26	0.28
0.26	0.26	0.27	0.26	0.27	0.25	0.27
0.25	0.25	0.26	0.25	0.26	0.25	0.26
0.24	0.24	0.24	0.24	0.25	0.24	0.25

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 28/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	3.05	INF	2.02	INF
10	2.37	INF	1.71	INF
5	1.94	INF	1.48	INF
3	1.56	INF	1.25	INF
2	1.25	INF	1.05	INF
1.6	1.09	8.75	0.94	INF
1.4	1	4.69	0.87	33.85
1.2	0.9	2.9	0.8	6.04
1	0.79	1.89	0.71	2.81
0.9	0.73	1.54	0.66	2.07
0.8	0.66	1.24	0.61	1.56
0.75	0.63	1.12	0.58	1.36
0.7	0.6	1	0.55	1.19
0.65	0.56	0.89	0.53	1.03
0.6	0.5	0.8	0.5	0.9
0.55	0.5	0.7	0.5	0.8
0.5	0.5	0.6	0.4	0.7
0.48	0.4	0.6	0.4	0.6
0.46	0.42	0.55	0.4	0.59
0.44	0.4	0.52	0.39	0.56
0.42	0.39	0.49	0.37	0.52
0.4	0.37	0.46	0.36	0.49
0.39	0.36	0.45	0.35	0.47
0.38	0.35	0.43	0.34	0.45
0.37	0.35	0.42	0.34	0.44
0.36	0.34	0.4	0.33	0.42
0.35	0.33	0.39	0.32	0.41
0.34	0.32	0.38	0.31	0.39
0.33	0.3	0.4	0.3	0.4
0.32	0.3	0.4	0.3	0.4
0.31	0.3	0.3	0.3	0.4
0.3	0.3	0.3	0.3	0.3
0.29	0.28	0.31	0.27	0.32
0.28	0.27	0.3	0.26	0.31
0.27	0.26	0.29	0.26	0.29
0.26	0.25	0.28	0.25	0.28
0.25	0.24	0.26	0.24	0.27
0.24	0.23	0.25	0.23	0.26

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	26.21	INF	28.88	INF	24.38	INF
10	7.28	16.06	7.46	29.74	7.13	INF
6	4.91	7.73	4.99	9.89	4.84	15.18
4	3.49	4.69	3.53	5.39	3.46	6.63
3	2.71	3.36	2.73	3.7	2.69	4.24
2.5	2.3	2.74	2.31	2.96	2.28	3.29
2	1.87	2.15	1.88	2.28	1.86	2.46
1.8	1.7	1.92	1.7	2.02	1.69	2.16
1.6	1.52	1.69	1.52	1.77	1.51	1.88
1.4	1.34	1.47	1.34	1.53	1.33	1.6
1.3	1.25	1.36	1.25	1.41	1.24	1.47
1.2	1.15	1.25	1.16	1.29	1.15	1.34
1.1	1.06	1.14	1.07	1.17	1.06	1.22
1	0.97	1.03	0.97	1.06	0.97	1.09
0.95	0.92	0.98	0.93	1	0.92	1.03
0.9	0.88	0.93	0.88	0.95	0.87	0.97
0.85	0.83	0.87	0.83	0.89	0.83	0.91
0.8	0.78	0.82	0.78	0.83	0.78	0.85
0.75	0.73	0.77	0.74	0.78	0.73	0.8
0.7	0.69	0.71	0.69	0.73	0.68	0.74
0.65	0.64	0.66	0.64	0.67	0.64	0.68
0.6	0.59	0.61	0.59	0.62	0.59	0.63
0.58	0.57	0.59	0.57	0.6	0.57	0.61
0.56	0.55	0.57	0.55	0.57	0.55	0.58
0.54	0.53	0.55	0.53	0.55	0.53	0.56
0.52	0.51	0.53	0.51	0.53	0.51	0.54
0.5	0.49	0.51	0.49	0.51	0.49	0.52
0.49	0.48	0.5	0.48	0.5	0.48	0.51
0.48	0.47	0.49	0.47	0.49	0.47	0.5
0.47	0.46	0.48	0.47	0.48	0.46	0.48
0.46	0.45	0.47	0.46	0.47	0.45	0.47
0.45	0.45	0.45	0.45	0.46	0.44	0.46
0.44	0.44	0.44	0.44	0.45	0.44	0.45
0.43	0.43	0.43	0.43	0.44	0.43	0.44
0.42	0.42	0.42	0.42	0.43	0.42	0.43
0.41	0.41	0.41	0.41	0.42	0.41	0.42
0.4	0.4	0.4	0.4	0.41	0.4	0.41
0.39	0.39	0.39	0.39	0.4	0.39	0.4
0.38	0.38	0.38	0.38	0.39	0.38	0.39
0.37	0.37	0.37	0.37	0.38	0.37	0.38
0.36	0.36	0.36	0.36	0.36	0.36	0.37
0.35	0.35	0.35	0.35	0.35	0.35	0.36
0.34	0.34	0.34	0.34	0.34	0.34	0.35
0.33	0.33	0.33	0.33	0.33	0.33	0.34
0.32	0.32	0.32	0.32	0.32	0.32	0.33
0.31	0.31	0.31	0.31	0.31	0.31	0.31
0.3	0.3	0.3	0.3	0.3	0.3	0.3

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	16.69	INF	10.56	INF	6.67	INF
10	6.29	INF	5.18	INF	4.04	INF
6	4.45	39.31	3.87	INF	3.2	INF
4	3.25	9	2.94	16.01	2.54	INF
3	2.57	5.08	2.37	6.72	2.11	11.49
2.5	2.19	3.77	2.05	4.59	1.85	6.37
2	1.8	2.72	1.7	3.11	1.57	3.82
1.8	1.64	2.35	1.56	2.64	1.45	3.12
1.6	1.47	2.02	1.41	2.22	1.32	2.55
1.4	1.3	1.7	1.25	1.84	1.18	2.06
1.3	1.22	1.55	1.17	1.67	1.11	1.84
1.2	1.13	1.41	1.09	1.5	1.04	1.64
1.1	1.04	1.27	1.01	1.34	0.97	1.45
1	0.95	1.13	0.93	1.19	0.89	1.27
0.95	0.91	1.07	0.88	1.12	0.85	1.19
0.9	0.86	1	0.84	1.05	0.81	1.11
0.85	0.82	0.94	0.8	0.98	0.77	1.03
0.8	0.77	0.88	0.75	0.91	0.73	0.95
0.75	0.72	0.82	0.71	0.84	0.69	0.88
0.7	0.68	0.76	0.67	0.78	0.65	0.81
0.65	0.63	0.7	0.62	0.72	0.61	0.74
0.6	0.58	0.64	0.58	0.65	0.56	0.67
0.58	0.57	0.62	0.56	0.63	0.55	0.65
0.56	0.55	0.59	0.54	0.61	0.53	0.62
0.54	0.53	0.57	0.52	0.58	0.51	0.6
0.52	0.51	0.55	0.5	0.56	0.49	0.57
0.5	0.49	0.52	0.48	0.53	0.48	0.55
0.49	0.48	0.51	0.48	0.52	0.47	0.53
0.48	0.47	0.5	0.47	0.51	0.46	0.52
0.47	0.46	0.49	0.46	0.5	0.45	0.51
0.46	0.45	0.48	0.45	0.49	0.44	0.5
0.45	0.44	0.47	0.44	0.48	0.43	0.48
0.44	0.43	0.46	0.43	0.46	0.42	0.47
0.43	0.42	0.45	0.42	0.45	0.41	0.46
0.42	0.41	0.44	0.41	0.44	0.4	0.45
0.41	0.4	0.42	0.4	0.43	0.4	0.44
0.4	0.39	0.41	0.39	0.42	0.39	0.43
0.39	0.38	0.4	0.38	0.41	0.38	0.41
0.38	0.38	0.39	0.37	0.4	0.37	0.4
0.37	0.37	0.38	0.36	0.38	0.36	0.39
0.36	0.36	0.37	0.35	0.37	0.35	0.38
0.35	0.35	0.36	0.34	0.36	0.34	0.37
0.34	0.34	0.35	0.33	0.35	0.33	0.36
0.33	0.33	0.34	0.32	0.34	0.32	0.34
0.32	0.32	0.33	0.32	0.33	0.31	0.33
0.31	0.31	0.32	0.31	0.32	0.3	0.32
0.3	0.3	0.31	0.3	0.31	0.29	0.31

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	4.35	INF	2.93	INF
10	3.07	INF	2.3	INF
6	2.57	INF	2.01	INF
4	2.13	INF	1.74	INF
3	1.82	INF	1.53	INF
2.5	1.63	13.87	1.39	INF
2	1.41	5.6	1.23	16.7
1.8	1.31	4.2	1.16	8.31
1.6	1.21	3.21	1.08	5.1
1.4	1.09	2.46	0.99	3.41
1.3	1.03	2.15	0.94	2.83
1.2	0.97	1.87	0.89	2.37
1.1	0.91	1.63	0.84	1.98
1	0.84	1.41	0.78	1.66
0.95	0.81	1.3	0.75	1.51
0.9	0.77	1.21	0.72	1.38
0.85	0.74	1.11	0.69	1.26
0.8	0.7	1.02	0.66	1.14
0.75	0.66	0.94	0.63	1.04
0.7	0.62	0.86	0.59	0.94
0.65	0.59	0.78	0.56	0.84
0.6	0.55	0.71	0.52	0.75
0.58	0.53	0.68	0.51	0.72
0.56	0.51	0.65	0.49	0.69
0.54	0.5	0.62	0.48	0.66
0.52	0.48	0.59	0.46	0.62
0.5	0.46	0.56	0.45	0.59
0.49	0.46	0.55	0.44	0.58
0.48	0.45	0.54	0.43	0.56
0.47	0.44	0.52	0.43	0.55
0.46	0.43	0.51	0.42	0.53
0.45	0.42	0.5	0.41	0.52
0.44	0.41	0.49	0.4	0.5
0.43	0.41	0.47	0.39	0.49
0.42	0.4	0.46	0.39	0.48
0.41	0.39	0.45	0.38	0.46
0.4	0.38	0.43	0.37	0.45
0.39	0.37	0.42	0.36	0.44
0.38	0.36	0.41	0.35	0.42
0.37	0.35	0.4	0.35	0.41
0.36	0.34	0.39	0.34	0.4
0.35	0.34	0.37	0.33	0.38
0.34	0.33	0.36	0.32	0.37
0.33	0.32	0.35	0.31	0.36
0.32	0.31	0.34	0.3	0.35
0.31	0.3	0.33	0.3	0.33
0.3	0.29	0.31	0.29	0.32

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	43.50	INF	24.65	INF	14.45	INF
20	13.72	INF	11.07	INF	8.42	INF
10	8.15	51.83	7.14	INF	5.94	INF
7	6.04	15.94	5.47	27.08	4.74	INF
5	4.49	8.29	4.17	10.52	3.74	15.96
4	3.67	5.84	3.46	6.85	3.16	8.79
3.5	3.25	4.82	3.08	5.49	2.84	6.65
3	2.81	3.91	2.69	4.33	2.5	5.03
2.5	2.37	3.09	2.28	3.35	2.15	3.74
2.2	2.1	2.64	2.03	2.82	1.92	3.1
2	1.92	2.35	1.86	2.5	1.77	2.71
1.8	1.73	2.08	1.69	2.19	1.61	2.35
1.6	1.55	1.81	1.51	1.9	1.45	2.01
1.5	1.45	1.68	1.42	1.75	1.37	1.85
1.4	1.36	1.56	1.33	1.62	1.29	1.7
1.3	1.27	1.43	1.24	1.48	1.2	1.55
1.2	1.17	1.31	1.15	1.35	1.12	1.41
1.1	1.08	1.19	1.06	1.22	1.03	1.27
1	0.98	1.07	0.97	1.1	0.94	1.14
0.95	0.93	1.02	0.92	1.04	0.9	1.07
0.9	0.88	0.96	0.87	0.98	0.85	1.01
0.85	0.84	0.9	0.83	0.92	0.81	0.94
0.8	0.79	0.84	0.78	0.86	0.76	0.88
0.78	0.77	0.82	0.76	0.84	0.75	0.86
0.76	0.75	0.8	0.74	0.81	0.73	0.83
0.74	0.73	0.78	0.72	0.79	0.71	0.81
0.72	0.71	0.75	0.7	0.77	0.69	0.78
0.7	0.69	0.73	0.68	0.74	0.67	0.76
0.68	0.67	0.71	0.66	0.72	0.66	0.73
0.66	0.65	0.69	0.65	0.7	0.64	0.71
0.64	0.63	0.67	0.63	0.68	0.62	0.69
0.62	0.61	0.64	0.61	0.65	0.6	0.66
0.6	0.59	0.62	0.59	0.63	0.58	0.64
0.59	0.58	0.61	0.58	0.62	0.57	0.63
0.58	0.57	0.6	0.57	0.61	0.56	0.62
0.57	0.56	0.59	0.56	0.6	0.55	0.61
0.56	0.55	0.58	0.55	0.59	0.54	0.59
0.55	0.54	0.57	0.54	0.57	0.53	0.58
0.54	0.53	0.56	0.53	0.56	0.53	0.57
0.53	0.52	0.55	0.52	0.55	0.52	0.56
0.52	0.52	0.54	0.51	0.54	0.51	0.55
0.51	0.51	0.52	0.5	0.53	0.5	0.54
0.5	0.5	0.51	0.49	0.52	0.49	0.53
0.49	0.49	0.5	0.48	0.51	0.48	0.51
0.48	0.48	0.49	0.47	0.5	0.47	0.5
0.47	0.47	0.48	0.46	0.49	0.46	0.49
0.46	0.46	0.47	0.45	0.48	0.45	0.48
0.45	0.45	0.46	0.44	0.46	0.44	0.47

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	9.02	INF	5.87	INF
20	6.25	INF	4.56	INF
10	4.78	INF	3.73	INF
7	3.98	INF	3.23	INF
5	3.25	55.54	2.74	INF
4	2.8	14.39	2.41	INF
3.5	2.55	9.41	2.23	22.44
3	2.28	6.44	2.02	10.63
2.5	1.98	4.47	1.78	6.12
2.2	1.79	3.57	1.63	4.54
2	1.66	3.06	1.52	3.74
1.8	1.52	2.6	1.4	3.08
1.6	1.38	2.19	1.28	2.52
1.5	1.3	2.01	1.22	2.27
1.4	1.23	1.83	1.15	2.04
1.3	1.15	1.66	1.09	1.83
1.2	1.07	1.49	1.02	1.63
1.1	0.99	1.34	0.95	1.44
1	0.91	1.19	0.87	1.27
0.95	0.87	1.12	0.84	1.19
0.9	0.83	1.05	0.8	1.11
0.85	0.79	0.98	0.76	1.03
0.8	0.75	0.91	0.72	0.96
0.78	0.73	0.88	0.7	0.93
0.76	0.71	0.86	0.69	0.9
0.74	0.69	0.83	0.67	0.87
0.72	0.68	0.81	0.66	0.84
0.7	0.66	0.78	0.64	0.81
0.68	0.64	0.75	0.62	0.78
0.66	0.62	0.73	0.61	0.76
0.64	0.61	0.7	0.59	0.73
0.62	0.59	0.68	0.57	0.7
0.6	0.57	0.65	0.56	0.68
0.59	0.56	0.64	0.55	0.66
0.58	0.55	0.63	0.54	0.65
0.57	0.54	0.62	0.53	0.64
0.56	0.54	0.61	0.52	0.62
0.55	0.53	0.59	0.51	0.61
0.54	0.52	0.58	0.51	0.6
0.53	0.51	0.57	0.5	0.59
0.52	0.5	0.56	0.49	0.57
0.51	0.49	0.55	0.48	0.56
0.5	0.48	0.53	0.47	0.55
0.49	0.47	0.52	0.46	0.54
0.48	0.46	0.51	0.45	0.52
0.47	0.45	0.5	0.45	0.51
0.46	0.44	0.49	0.44	0.5
0.45	0.44	0.48	0.43	0.49

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	100.99	INF	88.66	INF	76.47	INF
50	33.49	58.69	32.02	77.59	30.28	INF
20	16.73	21.26	16.35	23.3	15.88	27.03
15	13.09	15.7	12.86	16.78	12.57	18.62
12	10.75	12.44	10.59	13.11	10.39	14.2
10	9.12	10.3	9.01	10.76	8.86	11.48
8	7.43	8.19	7.35	8.47	7.26	8.91
7	6.56	7.15	6.5	7.36	6.43	7.69
6	5.68	6.11	5.63	6.26	5.58	6.5
5.5	5.23	5.59	5.19	5.72	5.14	5.91
5	4.77	5.07	4.74	5.18	4.7	5.34
4.5	4.32	4.56	4.29	4.64	4.26	4.77
4	3.86	4.05	3.84	4.11	3.81	4.21
3.8	3.67	3.84	3.65	3.9	3.63	3.99
3.6	3.48	3.64	3.47	3.69	3.45	3.77
3.4	3.3	3.43	3.28	3.48	3.26	3.55
3.2	3.11	3.23	3.1	3.27	3.08	3.33
3	2.92	3.03	2.91	3.06	2.89	3.11
2.8	2.73	2.82	2.72	2.85	2.71	2.9
2.6	2.54	2.62	2.53	2.65	2.52	2.68
2.4	2.35	2.42	2.34	2.44	2.33	2.47
2.2	2.16	2.21	2.15	2.23	2.14	2.26
2	1.97	2.01	1.96	2.03	1.95	2.05
1.9	1.87	1.91	1.86	1.92	1.86	1.94
1.8	1.77	1.81	1.77	1.82	1.76	1.84
1.7	1.68	1.71	1.67	1.72	1.67	1.73
1.6	1.58	1.61	1.58	1.62	1.57	1.63
1.5	1.48	1.51	1.48	1.51	1.47	1.53
1.4	1.38	1.41	1.38	1.41	1.38	1.42
1.3	1.29	1.3	1.28	1.31	1.28	1.32
1.2	1.19	1.2	1.19	1.21	1.18	1.22
1.1	1.09	1.1	1.09	1.11	1.09	1.11
1	0.99	1	0.99	1.01	0.99	1.01

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	58.31	INF	41.65	INF	28.93	INF
50	26.96	INF	22.77	INF	18.37	INF
20	14.93	33.15	13.55	46.26	11.87	96.14
15	11.96	21.32	11.06	26.06	9.92	36.77
12	9.98	15.72	9.35	18.14	8.52	22.73
10	8.56	12.44	8.09	13.91	7.47	16.45
8	7.05	9.48	6.74	10.3	6.3	11.63
7	6.27	8.1	6.02	8.7	5.67	9.62
6	5.46	6.79	5.26	7.2	5	7.81
5.5	5.04	6.15	4.88	6.49	4.65	6.98
5	4.62	5.53	4.48	5.8	4.29	6.19
4.5	4.19	4.92	4.08	5.13	3.92	5.44
4	3.75	4.33	3.66	4.49	3.53	4.72
3.8	3.58	4.1	3.5	4.24	3.38	4.44
3.6	3.4	3.86	3.33	3.99	3.22	4.17
3.4	3.22	3.63	3.16	3.74	3.06	3.9
3.2	3.04	3.4	2.98	3.5	2.9	3.64
3	2.86	3.18	2.81	3.26	2.73	3.38
2.8	2.68	2.95	2.63	3.03	2.57	3.13
2.6	2.5	2.73	2.46	2.79	2.4	2.88
2.4	2.31	2.51	2.28	2.56	2.23	2.63
2.2	2.13	2.29	2.1	2.33	2.06	2.39
2	1.94	2.07	1.92	2.11	1.88	2.16
1.9	1.85	1.97	1.82	2	1.79	2.04
1.8	1.75	1.86	1.73	1.89	1.7	1.92
1.7	1.66	1.75	1.64	1.78	1.62	1.81
1.6	1.56	1.65	1.55	1.67	1.53	1.69
1.5	1.47	1.54	1.45	1.56	1.43	1.58
1.4	1.37	1.43	1.36	1.45	1.34	1.47
1.3	1.28	1.33	1.27	1.34	1.25	1.36
1.2	1.18	1.22	1.17	1.24	1.16	1.25
1.1	1.08	1.12	1.08	1.13	1.07	1.14
1	0.99	1.02	0.98	1.02	0.97	1.03

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	20.13	INF	14.06	INF
50	14.39	INF	11.01	INF
20	10.08	INF	8.3	INF
15	8.64	86.31	7.3	INF
12	7.56	35.17	6.52	153.81
10	6.72	22.08	5.89	42.7
8	5.76	14.17	5.14	20.49
7	5.23	11.29	4.71	14.94
6	4.66	8.87	4.24	10.98
5.5	4.35	7.81	3.99	9.39
5	4.03	6.83	3.72	8
4.5	3.71	5.92	3.44	6.78
4	3.36	5.08	3.15	5.69
3.8	3.22	4.76	3.02	5.29
3.6	3.08	4.44	2.9	4.9
3.4	2.93	4.14	2.77	4.54
3.2	2.78	3.84	2.64	4.18
3	2.63	3.56	2.5	3.84
2.8	2.48	3.28	2.36	3.51
2.6	2.32	3	2.22	3.2
2.4	2.16	2.74	2.07	2.9
2.2	2	2.48	1.92	2.61
2	1.83	2.22	1.77	2.33
1.9	1.75	2.1	1.69	2.19
1.8	1.67	1.98	1.62	2.06
1.7	1.58	1.86	1.54	1.93
1.6	1.5	1.74	1.45	1.8
1.5	1.41	1.62	1.37	1.67
1.4	1.32	1.5	1.29	1.54
1.3	1.23	1.38	1.21	1.42
1.2	1.14	1.27	1.12	1.3
1.1	1.05	1.16	1.03	1.18
1	0.96	1.05	0.95	1.07

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	191.80	INF	178.29	INF	123.99	INF
100	65.79	INF	64.12	INF	55.41	INF
90	61.31	INF	59.86	INF	52.2	INF
80	56.51	INF	55.27	INF	48.68	INF
70	51.33	INF	50.31	INF	44.79	INF
60	45.75	87.22	44.94	INF	40.48	INF
50	39.7	67.56	39.09	85.57	35.68	INF
45	36.49	58.73	35.97	71.87	33.06	96.06
40	33.13	50.48	32.7	59.89	30.29	75.78
35	29.63	42.76	29.29	49.31	27.33	59.59
30	25.97	35.52	25.71	39.92	24.19	46.39
25	22.14	28.71	21.95	31.51	20.84	35.4
20	18.13	22.3	18	23.95	17.25	26.12
15	13.93	16.25	13.85	17.1	13.4	18.18
14	13.06	15.08	13	15.81	12.6	16.73
13	12.19	13.93	12.13	14.55	11.79	15.32
12	11.31	12.79	11.26	13.3	10.96	13.94
11	10.42	11.66	10.37	12.08	10.12	12.61
10	9.52	10.54	9.48	10.88	9.27	11.31
9.5	9.06	9.98	9.03	10.29	8.84	10.67
9	8.61	9.43	8.58	9.71	8.41	10.04
8.5	8.15	8.88	8.12	9.13	7.97	9.42
8	7.69	8.34	7.67	8.55	7.53	8.81
7.5	7.23	7.8	7.21	7.98	7.08	8.2
7	6.76	7.26	6.74	7.42	6.64	7.61
6.5	6.29	6.72	6.28	6.86	6.19	7.02
6	5.82	6.19	5.81	6.3	5.73	6.44
5.5	5.35	5.66	5.34	5.75	5.28	5.86
5	4.88	5.13	4.87	5.21	4.81	5.3
4.8	4.69	4.92	4.68	4.99	4.63	5.07
4.6	4.5	4.71	4.49	4.77	4.44	4.85
4.5	4.4	4.6	4.39	4.66	4.35	4.74
4.4	4.31	4.5	4.3	4.56	4.26	4.63
4.2	4.11	4.29	4.11	4.34	4.07	4.41
4	3.92	4.08	3.92	4.13	3.88	4.18
3.8	3.73	3.87	3.73	3.92	3.69	3.97
3.6	3.54	3.66	3.53	3.7	3.5	3.75
3.5	3.44	3.56	3.44	3.6	3.41	3.64
3.4	3.34	3.46	3.34	3.49	3.32	3.53
3.2	3.15	3.25	3.15	3.28	3.13	3.31
3	2.96	3.04	2.95	3.07	2.93	3.1
2.9	2.86	2.94	2.86	2.96	2.84	2.99
2.8	2.76	2.84	2.76	2.86	2.74	2.89
2.7	2.67	2.74	2.66	2.76	2.65	2.78
2.6	2.57	2.63	2.57	2.65	2.55	2.67

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
2.5	2.47	2.53	2.47	2.55	2.46	2.57
2.4	2.37	2.43	2.37	2.44	2.36	2.46
2.3	2.28	2.33	2.27	2.34	2.26	2.36
2.2	2.18	2.22	2.18	2.24	2.17	2.25
2.1	2.08	2.12	2.08	2.13	2.07	2.15
2	1.98	2.02	1.98	2.03	1.97	2.04
1.95	1.93	1.97	1.93	1.98	1.92	1.99
1.9	1.88	1.92	1.88	1.93	1.87	1.94
1.85	1.83	1.87	1.83	1.87	1.83	1.89
1.8	1.79	1.81	1.78	1.82	1.78	1.83
1.75	1.74	1.76	1.74	1.77	1.73	1.78
1.7	1.69	1.71	1.69	1.72	1.68	1.73
1.65	1.64	1.66	1.64	1.67	1.63	1.68
1.6	1.59	1.61	1.59	1.62	1.58	1.63
1.55	1.54	1.56	1.54	1.57	1.53	1.57
1.5	1.49	1.51	1.49	1.52	1.48	1.52
1.45	1.44	1.46	1.44	1.46	1.44	1.47
1.4	1.39	1.41	1.39	1.41	1.39	1.42
1.35	1.34	1.36	1.34	1.36	1.34	1.37
1.3	1.29	1.31	1.29	1.31	1.29	1.32
1.25	1.24	1.26	1.24	1.26	1.24	1.26
1.2	1.19	1.21	1.19	1.21	1.19	1.21
1.15	1.14	1.16	1.14	1.16	1.14	1.16
1.1	1.1	1.1	1.09	1.11	1.09	1.11
1.05	1.05	1.05	1.05	1.06	1.04	1.06
1	1	1	1	1.01	0.99	1.01
0.98	0.98	0.98	0.98	0.99	0.97	0.99
0.96	0.96	0.96	0.96	0.97	0.95	0.97
0.95	0.95	0.95	0.95	0.96	0.94	0.96
0.94	0.94	0.94	0.94	0.95	0.93	0.95
0.92	0.92	0.92	0.92	0.92	0.92	0.93
0.9	0.9	0.9	0.9	0.9	0.9	0.91
0.88	0.88	0.88	0.88	0.88	0.88	0.89
0.86	0.86	0.86	0.86	0.86	0.86	0.87
0.85	0.85	0.85	0.85	0.85	0.85	0.86
0.84	0.84	0.84	0.84	0.84	0.84	0.85
0.82	0.82	0.82	0.82	0.82	0.82	0.83
0.8	0.8	0.8	0.8	0.8	0.8	0.8
0.78	0.78	0.78	0.78	0.78	0.78	0.78
0.76	0.76	0.76	0.76	0.76	0.76	0.76
0.75	0.75	0.75	0.75	0.75	0.75	0.75
0.74	0.74	0.74	0.74	0.74	0.74	0.74
0.72	0.72	0.72	0.72	0.72	0.72	0.72
0.7	0.7	0.7	0.7	0.7	0.7	0.7

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	85.31	INF	58.55	INF	40.08	INF
100	46.1	INF	36.98	INF	28.66	INF
90	43.86	INF	35.53	INF	27.78	INF
80	41.34	INF	33.87	INF	26.76	INF
70	38.51	INF	31.94	INF	25.54	INF
60	35.28	INF	29.69	INF	24.09	INF
50	31.58	INF	27.03	INF	22.31	INF
45	29.51	INF	25.5	INF	21.26	INF
40	27.28	INF	23.82	INF	20.08	INF
35	24.87	82.82	21.96	INF	18.75	INF
30	22.24	59.32	19.89	INF	17.22	INF
25	19.38	42.45	17.57	58.32	15.46	INF
20	16.24	29.76	14.95	36.75	13.4	54.12
15	12.79	19.86	11.98	22.73	10.96	28.33
14	12.06	18.14	11.34	20.5	10.42	24.94
13	11.31	16.49	10.67	18.41	9.86	21.91
12	10.55	14.9	9.99	16.46	9.28	19.19
11	9.77	13.39	9.29	14.62	8.67	16.74
10	8.97	11.93	8.57	12.9	8.04	14.51
9.5	8.57	11.22	8.2	12.07	7.72	13.47
9	8.16	10.53	7.83	11.27	7.39	12.48
8.5	7.75	9.85	7.45	10.49	7.05	11.53
8	7.33	9.18	7.06	9.74	6.7	10.62
7.5	6.91	8.52	6.67	9	6.35	9.75
7	6.49	7.88	6.28	8.29	5.99	8.92
6.5	6.06	7.25	5.87	7.59	5.62	8.11
6	5.62	6.63	5.46	6.91	5.25	7.34
5.5	5.18	6.02	5.05	6.25	4.86	6.6
5	4.74	5.43	4.62	5.61	4.47	5.89
4.8	4.56	5.19	4.45	5.36	4.31	5.61
4.6	4.38	4.96	4.28	5.11	4.15	5.34
4.5	4.29	4.84	4.19	4.99	4.07	5.2
4.4	4.2	4.72	4.11	4.86	3.99	5.07
4.2	4.01	4.49	3.93	4.62	3.82	4.8
4	3.83	4.26	3.76	4.38	3.66	4.54
3.8	3.65	4.04	3.58	4.14	3.49	4.28
3.6	3.46	3.81	3.4	3.9	3.32	4.03
3.5	3.37	3.7	3.32	3.78	3.24	3.9
3.4	3.28	3.59	3.23	3.66	3.15	3.78
3.2	3.09	3.36	3.05	3.43	2.98	3.53
3	2.91	3.14	2.87	3.2	2.81	3.29
2.9	2.81	3.03	2.77	3.09	2.72	3.17
2.8	2.72	2.92	2.68	2.97	2.63	3.05
2.7	2.62	2.81	2.59	2.86	2.54	2.93
2.6	2.53	2.7	2.5	2.75	2.46	2.81

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
2.5	2.44	2.60	2.41	2.64	2.37	2.69
2.4	2.34	2.49	2.31	2.52	2.28	2.57
2.3	2.25	2.38	2.22	2.41	2.19	2.46
2.2	2.15	2.27	2.13	2.3	2.1	2.34
2.1	2.06	2.17	2.04	2.19	2.01	2.23
2	1.96	2.06	1.94	2.08	1.92	2.12
1.95	1.91	2.01	1.89	2.03	1.87	2.06
1.9	1.86	1.95	1.85	1.97	1.82	2
1.85	1.82	1.9	1.8	1.92	1.78	1.95
1.8	1.77	1.85	1.75	1.87	1.73	1.89
1.75	1.72	1.79	1.71	1.81	1.69	1.84
1.7	1.67	1.74	1.66	1.76	1.64	1.78
1.65	1.62	1.69	1.61	1.7	1.59	1.73
1.6	1.57	1.64	1.56	1.65	1.55	1.67
1.55	1.53	1.58	1.52	1.6	1.5	1.62
1.5	1.48	1.53	1.47	1.54	1.45	1.56
1.45	1.43	1.48	1.42	1.49	1.41	1.51
1.4	1.38	1.43	1.37	1.44	1.36	1.45
1.35	1.33	1.37	1.33	1.38	1.31	1.4
1.3	1.28	1.32	1.28	1.33	1.27	1.34
1.25	1.24	1.27	1.23	1.28	1.22	1.29
1.2	1.19	1.22	1.18	1.23	1.17	1.24
1.15	1.14	1.17	1.13	1.17	1.12	1.18
1.1	1.09	1.12	1.08	1.12	1.08	1.13
1.05	1.04	1.06	1.04	1.07	1.03	1.08
1	0.99	1.01	0.99	1.02	0.98	1.02
0.98	0.97	0.99	0.97	1	0.96	1
0.96	0.95	0.97	0.95	0.98	0.94	0.98
0.95	0.94	0.96	0.94	0.96	0.93	0.97
0.94	0.93	0.95	0.93	0.95	0.92	0.96
0.92	0.91	0.93	0.91	0.93	0.9	0.94
0.9	0.89	0.91	0.89	0.91	0.89	0.92
0.88	0.87	0.89	0.87	0.89	0.87	0.9
0.86	0.85	0.87	0.85	0.87	0.85	0.88
0.85	0.84	0.86	0.84	0.86	0.84	0.87
0.84	0.83	0.85	0.83	0.85	0.83	0.86
0.82	0.81	0.83	0.81	0.83	0.81	0.83
0.8	0.79	0.81	0.79	0.81	0.79	0.81
0.78	0.78	0.79	0.77	0.79	0.77	0.79
0.76	0.76	0.77	0.75	0.77	0.75	0.77
0.75	0.75	0.76	0.74	0.76	0.74	0.76
0.74	0.74	0.75	0.73	0.75	0.73	0.75
0.72	0.72	0.73	0.71	0.73	0.71	0.73
0.7	0.7	0.7	0.69	0.71	0.69	0.71

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	27.46	INF	18.97	INF
100	21.59	INF	15.98	INF
90	21.09	INF	15.7	INF
80	20.49	INF	15.37	INF
70	19.78	INF	14.97	INF
60	18.89	INF	14.46	INF
50	17.78	INF	13.8	INF
45	17.11	INF	13.4	INF
40	16.34	INF	12.92	INF
35	15.45	INF	12.36	INF
30	14.4	INF	11.68	INF
25	13.15	INF	10.85	INF
20	11.63	INF	9.8	INF
15	9.76	42.84	8.44	INF
14	9.33	35.51	8.12	87.72
13	8.88	29.65	7.78	58.87
12	8.4	24.87	7.41	42.55
11	7.91	20.89	7.02	32.05
10	7.38	17.52	6.61	24.72
9.5	7.11	16.02	6.39	21.83
9	6.83	14.64	6.16	19.33
8.5	6.54	13.34	5.92	17.13
8	6.24	12.14	5.68	15.18
7.5	5.93	11.01	5.43	13.45
7	5.62	9.95	5.16	11.9
6.5	5.3	8.96	4.89	10.51
6	4.96	8.03	4.61	9.24
5.5	4.62	7.15	4.31	8.09
5	4.26	6.32	4	7.04
4.8	4.12	6	3.87	6.64
4.6	3.97	5.69	3.74	6.26
4.5	3.9	5.53	3.68	6.07
4.4	3.82	5.38	3.61	5.89
4.2	3.67	5.08	3.48	5.53
4	3.52	4.79	3.34	5.18
3.8	3.37	4.5	3.2	4.85
3.6	3.21	4.22	3.06	4.52
3.5	3.13	4.08	2.99	4.36
3.4	3.05	3.94	2.92	4.21
3.2	2.89	3.67	2.77	3.9
3	2.73	3.41	2.62	3.6
2.9	2.64	3.28	2.55	3.46
2.8	2.56	3.15	2.47	3.31
2.7	2.48	3.02	2.39	3.17
2.6	2.4	2.9	2.31	3.03

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
2.5	2.31	2.77	2.24	2.89
2.4	2.23	2.65	2.16	2.76
2.3	2.14	2.53	2.08	2.63
2.2	2.05	2.4	2	2.49
2.1	1.97	2.28	1.91	2.36
2	1.88	2.16	1.83	2.24
1.95	1.84	2.11	1.79	2.17
1.9	1.79	2.05	1.75	2.11
1.85	1.75	1.99	1.71	2.05
1.8	1.7	1.93	1.66	1.99
1.75	1.66	1.87	1.62	1.92
1.7	1.61	1.81	1.58	1.86
1.65	1.57	1.76	1.54	1.8
1.6	1.53	1.7	1.49	1.74
1.55	1.48	1.64	1.45	1.68
1.5	1.43	1.59	1.41	1.62
1.45	1.39	1.53	1.36	1.56
1.4	1.34	1.47	1.32	1.5
1.35	1.3	1.42	1.28	1.45
1.3	1.25	1.36	1.23	1.39
1.25	1.21	1.31	1.19	1.33
1.2	1.16	1.25	1.14	1.27
1.15	1.11	1.2	1.1	1.22
1.1	1.07	1.14	1.05	1.16
1.05	1.02	1.09	1.01	1.1
1	0.97	1.03	0.96	1.05
0.98	0.95	1.01	0.94	1.02
0.96	0.94	0.99	0.93	1
0.95	0.93	0.98	0.92	0.99
0.94	0.92	0.97	0.91	0.98
0.92	0.9	0.95	0.89	0.96
0.9	0.88	0.93	0.87	0.94
0.88	0.86	0.9	0.85	0.91
0.86	0.84	0.88	0.83	0.89
0.85	0.83	0.87	0.82	0.88
0.84	0.82	0.86	0.82	0.87
0.82	0.8	0.84	0.8	0.85
0.8	0.78	0.82	0.78	0.83
0.78	0.77	0.8	0.76	0.8
0.76	0.75	0.78	0.74	0.78
0.75	0.74	0.77	0.73	0.77
0.74	0.73	0.76	0.72	0.76
0.72	0.71	0.73	0.7	0.74
0.7	0.69	0.71	0.68	0.72

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	53.65	INF	46.05	INF	48.53	INF
10	8.45	12.26	8.24	14.06	8.31	20.64
8	6.98	9.38	6.83	10.39	6.88	13.57
7	6.21	8.03	6.09	8.76	6.13	10.91
6	5.41	6.74	5.32	7.24	5.35	8.64
5	4.59	5.5	4.52	5.83	4.54	6.7
4	3.73	4.31	3.69	4.51	3.7	5
3	2.85	3.17	2.83	3.27	2.83	3.52
2.5	2.39	2.62	2.38	2.68	2.38	2.85
2	1.93	2.07	1.92	2.11	1.93	2.21
1.8	1.75	1.86	1.74	1.89	1.74	1.97
1.6	1.56	1.64	1.55	1.67	1.55	1.73
1.5	1.46	1.54	1.46	1.56	1.46	1.61
1.4	1.37	1.43	1.36	1.45	1.36	1.5
1.3	1.27	1.33	1.27	1.34	1.27	1.38
1.2	1.18	1.22	1.17	1.24	1.17	1.27
1.1	1.08	1.12	1.08	1.13	1.08	1.16
1	0.98	1.02	0.98	1.03	0.98	1.05
0.95	0.94	0.96	0.93	0.97	0.93	0.99
0.9	0.89	0.91	0.89	0.92	0.89	0.94
0.85	0.84	0.86	0.84	0.87	0.84	0.88
0.8	0.79	0.81	0.79	0.82	0.79	0.83
0.75	0.74	0.76	0.74	0.76	0.74	0.77
0.7	0.69	0.71	0.69	0.71	0.69	0.72
0.65	0.64	0.66	0.64	0.66	0.64	0.67
0.62	0.62	0.63	0.62	0.63	0.62	0.64
0.6	0.59	0.61	0.59	0.61	0.59	0.61
0.58	0.58	0.58	0.57	0.59	0.57	0.59
0.56	0.56	0.56	0.56	0.57	0.56	0.57
0.55	0.55	0.55	0.55	0.56	0.55	0.56
0.54	0.54	0.54	0.54	0.55	0.54	0.55
0.52	0.52	0.52	0.52	0.53	0.52	0.53

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	36.69	INF	22.61	INF	13.86	INF
10	7.88	40.63	6.96	INF	5.84	INF
8	6.59	20.02	5.93	41.79	5.11	INF
7	5.89	14.7	5.37	23.75	4.68	INF
6	5.17	10.85	4.76	15.07	4.22	29.66
5	4.41	7.94	4.11	9.97	3.7	14.74
4	3.62	5.66	3.42	6.62	3.13	8.4
3	2.78	3.83	2.66	4.24	2.49	4.9
2.5	2.35	3.04	2.26	3.29	2.14	3.67
2	1.9	2.33	1.85	2.47	1.76	2.67
1.8	1.72	2.06	1.68	2.16	1.61	2.32
1.6	1.54	1.8	1.5	1.88	1.45	1.99
1.5	1.45	1.67	1.41	1.74	1.37	1.83
1.4	1.35	1.55	1.33	1.6	1.28	1.68
1.3	1.26	1.42	1.24	1.47	1.2	1.54
1.2	1.17	1.3	1.15	1.34	1.11	1.4
1.1	1.07	1.18	1.05	1.22	1.03	1.26
1	0.98	1.07	0.96	1.09	0.94	1.13
0.95	0.93	1.01	0.92	1.03	0.9	1.06
0.9	0.88	0.95	0.87	0.97	0.85	1
0.85	0.83	0.9	0.82	0.91	0.81	0.94
0.8	0.79	0.84	0.78	0.86	0.76	0.88
0.75	0.74	0.78	0.73	0.8	0.72	0.81
0.7	0.69	0.73	0.68	0.74	0.67	0.75
0.65	0.64	0.67	0.64	0.68	0.63	0.7
0.62	0.61	0.65	0.61	0.65	0.6	0.66
0.6	0.59	0.62	0.59	0.63	0.58	0.64
0.58	0.57	0.6	0.57	0.61	0.56	0.61
0.56	0.55	0.58	0.55	0.58	0.54	0.59
0.55	0.54	0.57	0.54	0.57	0.53	0.58
0.54	0.53	0.56	0.53	0.56	0.52	0.57
0.52	0.51	0.53	0.51	0.54	0.51	0.55

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	8.82	INF	5.80	INF
10	4.72	INF	3.71	INF
8	4.23	INF	3.4	INF
7	3.94	INF	3.21	INF
6	3.61	INF	2.99	INF
5	3.23	42.29	2.72	INF
4	2.78	13.3	2.4	70.59
3	2.27	6.21	2.01	9.91
2.5	1.97	4.35	1.78	5.87
2	1.65	3	1.52	3.64
1.8	1.52	2.56	1.4	3.01
1.6	1.37	2.17	1.28	2.47
1.5	1.3	1.98	1.22	2.23
1.4	1.23	1.81	1.15	2.01
1.3	1.15	1.64	1.08	1.8
1.2	1.07	1.48	1.02	1.61
1.1	0.99	1.33	0.95	1.43
1	0.91	1.18	0.87	1.26
0.95	0.87	1.11	0.83	1.18
0.9	0.83	1.04	0.8	1.1
0.85	0.79	0.97	0.76	1.02
0.8	0.74	0.9	0.72	0.95
0.75	0.7	0.84	0.68	0.88
0.7	0.66	0.78	0.64	0.81
0.65	0.62	0.71	0.6	0.74
0.62	0.59	0.68	0.58	0.7
0.6	0.57	0.65	0.56	0.67
0.58	0.55	0.63	0.54	0.65
0.56	0.54	0.6	0.52	0.62
0.55	0.53	0.59	0.51	0.61
0.54	0.52	0.58	0.51	0.59
0.52	0.5	0.56	0.49	0.57

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.025 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
0.5	0.48	0.53	0.47	0.54
0.49	0.47	0.52	0.46	0.53
0.48	0.46	0.51	0.45	0.52
0.47	0.45	0.5	0.45	0.51
0.46	0.44	0.49	0.44	0.5
0.45	0.44	0.47	0.43	0.48
0.44	0.43	0.46	0.42	0.47
0.43	0.42	0.45	0.41	0.46
0.42	0.41	0.44	0.4	0.45
0.41	0.4	0.43	0.39	0.44
0.4	0.39	0.42	0.38	0.42
0.39	0.38	0.41	0.37	0.41
0.38	0.37	0.4	0.37	0.4
0.37	0.36	0.39	0.36	0.39
0.37	0.36	0.38	0.36	0.39
0.36	0.35	0.37	0.35	0.38
0.35	0.34	0.36	0.34	0.37
0.34	0.33	0.35	0.33	0.36
0.33	0.32	0.34	0.32	0.34
0.32	0.32	0.33	0.31	0.34
0.32	0.31	0.33	0.31	0.33
0.31	0.3	0.32	0.3	0.32
0.3	0.3	0.31	0.29	0.31
0.29	0.29	0.3	0.28	0.3
0.28	0.28	0.29	0.27	0.29
0.28	0.27	0.28	0.27	0.29
0.27	0.27	0.27	0.27	0.28
0.26	0.26	0.26	0.26	0.27
0.25	0.25	0.25	0.25	0.25
0.24	0.24	0.24	0.24	0.24
0.24	0.23	0.24	0.23	0.24

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 21/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	8		11		16	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	3.21	INF	2.22	INF	1.50	INF
10	2.47	INF	1.84	INF	1.32	INF
5	2.01	INF	1.58	INF	1.19	INF
3	1.60	INF	1.33	INF	1.04	INF
2	1.28	INF	1.10	INF	0.91	INF
1.7	1.16	23.06	1.01	INF	0.85	INF
1.5	1.07	7.58	0.95	INF	0.80	INF
1.3	0.97	4.04	0.87	32.04	0.75	INF
1.1	0.86	2.47	0.78	5.10	0.69	INF
1	0.80	1.97	0.73	3.30	0.65	35.39
0.9	0.74	1.58	0.68	2.31	0.61	6.00
0.8	0.67	1.27	0.63	1.68	0.57	2.95
0.75	0.64	1.14	0.60	1.44	0.55	2.26
0.7	0.60	1.01	0.57	1.24	0.52	1.79
0.65	0.57	0.90	0.54	1.07	0.50	1.44
0.6	0.53	0.80	0.51	0.92	0.47	1.17
0.55	0.49	0.70	0.47	0.80	0.44	0.96
0.5	0.46	0.62	0.44	0.68	0.41	0.79
0.48	0.44	0.58	0.42	0.64	0.40	0.73
0.46	0.42	0.55	0.41	0.60	0.39	0.68
0.44	0.41	0.52	0.39	0.56	0.38	0.63
0.42	0.39	0.49	0.38	0.53	0.36	0.58
0.4	0.37	0.46	0.36	0.49	0.35	0.54
0.39	0.37	0.45	0.36	0.47	0.34	0.52
0.38	0.36	0.43	0.35	0.46	0.33	0.50
0.37	0.35	0.42	0.34	0.44	0.33	0.48
0.36	0.34	0.40	0.33	0.42	0.32	0.46
0.35	0.33	0.39	0.32	0.41	0.31	0.44
0.34	0.32	0.38	0.32	0.39	0.31	0.42
0.33	0.31	0.36	0.31	0.38	0.30	0.40
0.32	0.31	0.35	0.30	0.36	0.29	0.38
0.31	0.30	0.34	0.29	0.35	0.28	0.37
0.3	0.29	0.32	0.28	0.34	0.28	0.35
0.29	0.28	0.31	0.28	0.32	0.27	0.34
0.28	0.27	0.30	0.27	0.31	0.26	0.32
0.27	0.26	0.29	0.26	0.29	0.25	0.30
0.26	0.25	0.27	0.25	0.28	0.24	0.29
0.25	0.24	0.26	0.24	0.27	0.24	0.28
0.24	0.23	0.25	0.23	0.26	0.23	0.26

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 21/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.03	INF
10	0.95	INF
5	0.89	INF
3	0.81	INF
2	0.73	INF
1.7	0.69	INF
1.5	0.66	INF
1.3	0.63	INF
1.1	0.59	INF
1	0.56	INF
0.9	0.53	INF
0.8	0.50	INF
0.75	0.49	13.73
0.7	0.47	4.99
0.65	0.45	2.88
0.6	0.43	1.93
0.55	0.41	1.39
0.5	0.38	1.05
0.48	0.37	0.94
0.46	0.36	0.85
0.44	0.35	0.76
0.42	0.34	0.69
0.4	0.33	0.62
0.39	0.32	0.59
0.38	0.32	0.56
0.37	0.31	0.54
0.36	0.31	0.51
0.35	0.30	0.49
0.34	0.29	0.46
0.33	0.29	0.44
0.32	0.28	0.42
0.31	0.27	0.40
0.3	0.27	0.38
0.29	0.26	0.36
0.28	0.25	0.34
0.27	0.25	0.32
0.26	0.24	0.30
0.25	0.23	0.29
0.24	0.22	0.27

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 25/T2.9 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop	
	22	
m	von / from	bis / to
INF	1.26	INF
4	0.99	INF
2	0.82	INF
1.3	0.69	INF
1	0.60	20.65
0.8	0.53	2.86
0.7	0.49	1.77
0.6	0.45	1.18
0.55	0.42	0.97
0.5	0.40	0.80
0.45	0.37	0.66
0.4	0.34	0.54
0.38	0.32	0.50
0.36	0.31	0.46
0.34	0.30	0.42
0.32	0.28	0.39
0.3	0.27	0.36
0.29	0.26	0.34
0.28	0.26	0.32
0.27	0.25	0.31
0.26	0.24	0.29
0.25	0.23	0.28
0.24	0.22	0.26
0.23	0.22	0.25
0.22	0.21	0.24
0.21	0.20	0.22
0.2	0.19	0.21
0.19	0.18	0.20
0.18	0.18	0.19
0.17	0.17	0.17

Schärfentieftabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 28/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	7.85	INF	5.61	INF	3.69	INF
10	4.44	INF	3.64	INF	2.73	INF
5	3.10	INF	2.69	INF	2.17	INF
3	2.21	10.43	2.00	INF	1.70	INF
2	1.62	3.7	1.51	5.85	1.34	20.19
1.6	1.35	2.49	1.28	3.29	1.15	5.38
1.4	1.21	2.02	1.15	2.5	1.05	3.53
1.2	1.06	1.62	1.01	1.9	0.94	2.42
1	0.9	1.26	0.87	1.42	0.82	1.68
0.9	0.82	1.1	0.8	1.22	0.75	1.4
0.8	0.74	0.95	0.72	1.03	0.68	1.15
0.75	0.7	0.88	0.68	0.95	0.65	1.05
0.7	0.66	0.81	0.64	0.86	0.61	0.94
0.65	0.61	0.74	0.6	0.78	0.58	0.85
0.6	0.6	0.7	0.6	0.7	0.5	0.8
0.55	0.5	0.6	0.5	0.6	0.5	0.7
0.5	0.5	0.5	0.5	0.6	0.5	0.6
0.48	0.5	0.5	0.5	0.5	0.4	0.6
0.46	0.44	0.5	0.44	0.51	0.43	0.54
0.44	0.43	0.47	0.42	0.49	0.41	0.51
0.42	0.41	0.45	0.4	0.46	0.39	0.48
0.4	0.39	0.42	0.38	0.44	0.38	0.45
0.39	0.38	0.41	0.37	0.42	0.37	0.44
0.38	0.37	0.4	0.37	0.41	0.36	0.42
0.37	0.36	0.39	0.36	0.4	0.35	0.41
0.36	0.35	0.38	0.35	0.39	0.34	0.4
0.35	0.34	0.37	0.34	0.37	0.33	0.38
0.34	0.33	0.36	0.33	0.36	0.32	0.37
0.33	0.3	0.3	0.3	0.4	0.3	0.4
0.32	0.3	0.3	0.3	0.3	0.3	0.4
0.31	0.3	0.3	0.3	0.3	0.3	0.3
0.3	0.3	0.3	0.3	0.3	0.3	0.3
0.29	0.29	0.3	0.28	0.3	0.28	0.31
0.28	0.28	0.29	0.27	0.29	0.27	0.3
0.27	0.27	0.28	0.26	0.28	0.26	0.29
0.26	0.26	0.27	0.26	0.27	0.25	0.27
0.25	0.25	0.26	0.25	0.26	0.24	0.26
0.24	0.24	0.25	0.24	0.25	0.23	0.25

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 28/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	2.44	INF	1.65	INF
10	1.99	INF	1.44	INF
5	1.68	INF	1.27	INF
3	1.39	INF	1.11	INF
2	1.14	INF	0.95	INF
1.6	1.01	38.34	0.86	INF
1.4	0.93	7.91	0.8	INF
1.2	0.84	3.84	0.74	24.22
1	0.75	2.24	0.67	4.24
0.9	0.69	1.75	0.62	2.73
0.8	0.64	1.38	0.58	1.9
0.75	0.61	1.22	0.56	1.6
0.7	0.58	1.08	0.53	1.36
0.65	0.54	0.95	0.5	1.16
0.6	0.5	0.8	0.5	1.0
0.55	0.5	0.7	0.5	0.8
0.5	0.4	0.6	0.4	0.7
0.48	0.4	0.6	0.4	0.7
0.46	0.41	0.57	0.39	0.63
0.44	0.4	0.54	0.38	0.59
0.42	0.38	0.5	0.36	0.55
0.4	0.36	0.47	0.35	0.51
0.39	0.36	0.46	0.34	0.49
0.38	0.35	0.44	0.34	0.47
0.37	0.34	0.43	0.33	0.45
0.36	0.33	0.41	0.32	0.44
0.35	0.32	0.4	0.31	0.42
0.34	0.32	0.38	0.31	0.4
0.33	0.3	0.4	0.3	0.4
0.32	0.3	0.4	0.3	0.4
0.31	0.3	0.3	0.3	0.4
0.3	0.3	0.3	0.3	0.3
0.29	0.28	0.32	0.27	0.33
0.28	0.27	0.3	0.26	0.31
0.27	0.26	0.29	0.25	0.3
0.26	0.25	0.28	0.24	0.29
0.25	0.24	0.27	0.24	0.27
0.24	0.23	0.25	0.23	0.26

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	21.86	INF	22.35	INF	18.09	INF
10	6.9	18.29	6.95	42.61	6.48	INF
6	4.74	8.2	4.76	10.98	4.54	19.38
4	3.41	4.86	3.42	5.69	3.3	7.31
3	2.66	3.45	2.66	3.84	2.59	4.5
2.5	2.26	2.8	2.26	3.05	2.21	3.45
2	1.85	2.18	1.85	2.33	1.82	2.55
1.8	1.68	1.95	1.68	2.06	1.65	2.23
1.6	1.5	1.71	1.5	1.8	1.48	1.92
1.4	1.33	1.48	1.33	1.55	1.31	1.64
1.3	1.24	1.37	1.24	1.42	1.22	1.5
1.2	1.15	1.26	1.15	1.3	1.14	1.36
1.1	1.06	1.15	1.06	1.18	1.05	1.23
1	0.96	1.04	0.96	1.07	0.96	1.11
0.95	0.92	0.99	0.92	1.01	0.91	1.05
0.9	0.87	0.93	0.87	0.95	0.87	0.98
0.85	0.82	0.88	0.82	0.9	0.82	0.92
0.8	0.78	0.82	0.78	0.84	0.77	0.86
0.75	0.73	0.77	0.73	0.78	0.73	0.8
0.7	0.68	0.72	0.68	0.73	0.68	0.75
0.65	0.64	0.66	0.64	0.67	0.63	0.69
0.6	0.59	0.61	0.59	0.62	0.59	0.63
0.58	0.57	0.59	0.57	0.6	0.57	0.61
0.56	0.55	0.57	0.55	0.58	0.55	0.59
0.54	0.53	0.55	0.53	0.56	0.53	0.56
0.52	0.51	0.53	0.51	0.53	0.51	0.54
0.5	0.49	0.51	0.49	0.51	0.49	0.52
0.49	0.48	0.5	0.48	0.5	0.48	0.51
0.48	0.47	0.49	0.47	0.49	0.47	0.5
0.47	0.46	0.48	0.46	0.48	0.46	0.49
0.46	0.45	0.47	0.45	0.47	0.45	0.48
0.45	0.44	0.46	0.44	0.46	0.44	0.47
0.44	0.43	0.45	0.43	0.45	0.43	0.45
0.43	0.42	0.44	0.42	0.44	0.42	0.44
0.42	0.42	0.43	0.42	0.43	0.41	0.43
0.41	0.41	0.41	0.41	0.42	0.4	0.42
0.4	0.4	0.4	0.4	0.41	0.39	0.41
0.39	0.39	0.39	0.39	0.4	0.39	0.4
0.38	0.38	0.38	0.38	0.39	0.38	0.39
0.37	0.37	0.37	0.37	0.38	0.37	0.38
0.36	0.36	0.36	0.36	0.37	0.36	0.37
0.35	0.35	0.35	0.35	0.35	0.35	0.36
0.34	0.34	0.34	0.34	0.34	0.34	0.35
0.33	0.33	0.33	0.33	0.33	0.33	0.34
0.32	0.32	0.32	0.32	0.32	0.32	0.33
0.31	0.31	0.31	0.31	0.31	0.31	0.32
0.3	0.3	0.3	0.3	0.3	0.3	0.3

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	12.50	INF	8.14	INF	5.28	INF
10	5.6	INF	4.53	INF	3.5	INF
6	4.09	INF	3.5	INF	2.85	INF
4	3.06	10.99	2.72	29.65	2.32	INF
3	2.45	5.65	2.23	8.29	1.96	21.52
2.5	2.11	4.07	1.94	5.26	1.74	8.55
2	1.74	2.87	1.63	3.4	1.49	4.49
1.8	1.59	2.46	1.5	2.84	1.38	3.56
1.6	1.44	2.09	1.36	2.36	1.26	2.82
1.4	1.27	1.76	1.22	1.93	1.14	2.23
1.3	1.19	1.6	1.14	1.74	1.07	1.97
1.2	1.11	1.44	1.07	1.56	1	1.74
1.1	1.02	1.3	0.99	1.39	0.94	1.53
1	0.94	1.16	0.91	1.23	0.86	1.33
0.95	0.89	1.09	0.87	1.15	0.83	1.24
0.9	0.85	1.02	0.83	1.07	0.79	1.15
0.85	0.81	0.96	0.78	1	0.75	1.07
0.8	0.76	0.89	0.74	0.93	0.72	0.99
0.75	0.72	0.83	0.7	0.86	0.68	0.91
0.7	0.67	0.77	0.66	0.79	0.64	0.83
0.65	0.63	0.71	0.61	0.73	0.6	0.76
0.6	0.58	0.65	0.57	0.66	0.55	0.69
0.58	0.56	0.62	0.55	0.64	0.54	0.66
0.56	0.54	0.6	0.53	0.61	0.52	0.63
0.54	0.52	0.57	0.52	0.59	0.5	0.61
0.52	0.51	0.55	0.5	0.56	0.49	0.58
0.5	0.49	0.53	0.48	0.54	0.47	0.55
0.49	0.48	0.52	0.47	0.53	0.46	0.54
0.48	0.47	0.51	0.46	0.52	0.45	0.53
0.47	0.46	0.49	0.45	0.5	0.44	0.52
0.46	0.45	0.48	0.44	0.49	0.44	0.5
0.45	0.44	0.47	0.43	0.48	0.43	0.49
0.44	0.43	0.46	0.43	0.47	0.42	0.48
0.43	0.42	0.45	0.42	0.46	0.41	0.47
0.42	0.41	0.44	0.41	0.44	0.4	0.45
0.41	0.4	0.43	0.4	0.43	0.39	0.44
0.4	0.39	0.42	0.39	0.42	0.38	0.43
0.39	0.38	0.4	0.38	0.41	0.37	0.42
0.38	0.37	0.39	0.37	0.4	0.37	0.41
0.37	0.36	0.38	0.36	0.39	0.36	0.39
0.36	0.35	0.37	0.35	0.38	0.35	0.38
0.35	0.34	0.36	0.34	0.36	0.34	0.37
0.34	0.34	0.35	0.33	0.35	0.33	0.36
0.33	0.33	0.34	0.32	0.34	0.32	0.35
0.32	0.32	0.33	0.31	0.33	0.31	0.34
0.31	0.31	0.32	0.3	0.32	0.3	0.32
0.3	0.3	0.31	0.29	0.31	0.29	0.31

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 35/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	3.52	INF	2.40	INF
10	2.64	INF	1.96	INF
6	2.26	INF	1.75	INF
4	1.92	INF	1.54	INF
3	1.66	INF	1.38	INF
2.5	1.51	69.69	1.27	INF
2	1.32	8.19	1.14	INF
1.8	1.23	5.5	1.07	25.65
1.6	1.14	3.9	1	8.64
1.4	1.04	2.84	0.93	4.66
1.3	0.99	2.43	0.89	3.63
1.2	0.93	2.08	0.84	2.89
1.1	0.87	1.78	0.79	2.33
1	0.81	1.52	0.74	1.89
0.95	0.78	1.4	0.72	1.7
0.9	0.75	1.28	0.69	1.53
0.85	0.71	1.18	0.66	1.38
0.8	0.68	1.08	0.63	1.24
0.75	0.64	0.98	0.6	1.12
0.7	0.61	0.89	0.57	1
0.65	0.57	0.81	0.54	0.89
0.6	0.53	0.73	0.51	0.79
0.58	0.52	0.7	0.5	0.75
0.56	0.5	0.67	0.48	0.72
0.54	0.49	0.64	0.47	0.68
0.52	0.47	0.61	0.45	0.65
0.5	0.46	0.58	0.44	0.61
0.49	0.45	0.56	0.43	0.6
0.48	0.44	0.55	0.42	0.58
0.47	0.43	0.54	0.42	0.57
0.46	0.42	0.52	0.41	0.55
0.45	0.42	0.51	0.4	0.53
0.44	0.41	0.49	0.4	0.52
0.43	0.4	0.48	0.39	0.5
0.42	0.39	0.47	0.38	0.49
0.41	0.38	0.45	0.37	0.47
0.4	0.38	0.44	0.36	0.46
0.39	0.37	0.43	0.36	0.45
0.38	0.36	0.42	0.35	0.43
0.37	0.35	0.4	0.34	0.42
0.36	0.34	0.39	0.33	0.4
0.35	0.33	0.38	0.32	0.39
0.34	0.32	0.37	0.32	0.38
0.33	0.32	0.35	0.31	0.36
0.32	0.31	0.34	0.3	0.35
0.31	0.3	0.33	0.29	0.34
0.3	0.29	0.32	0.28	0.32

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	46.20	INF	54.25	INF	52.28	INF
20	13.99	35.18	14.64	INF	14.49	INF
10	8.24	12.73	8.46	17.21	8.41	30.4
7	6.1	8.23	6.21	9.88	6.18	13.12
5	4.52	5.59	4.59	6.3	4.57	7.46
4	3.69	4.37	3.73	4.78	3.72	5.42
3.5	3.26	3.78	3.29	4.08	3.29	4.53
3	2.83	3.2	2.85	3.41	2.84	3.72
2.5	2.38	2.63	2.4	2.78	2.39	2.97
2.2	2.11	2.3	2.12	2.41	2.12	2.56
2	1.92	2.08	1.93	2.17	1.93	2.29
1.8	1.74	1.87	1.75	1.94	1.74	2.03
1.6	1.55	1.65	1.56	1.7	1.56	1.77
1.5	1.46	1.55	1.46	1.59	1.46	1.65
1.4	1.36	1.44	1.37	1.48	1.37	1.53
1.3	1.27	1.33	1.27	1.37	1.27	1.41
1.2	1.17	1.23	1.18	1.26	1.18	1.29
1.1	1.08	1.12	1.08	1.15	1.08	1.18
1	0.98	1.02	0.98	1.04	0.98	1.06
0.95	0.93	0.97	0.94	0.98	0.93	1
0.9	0.89	0.92	0.89	0.93	0.89	0.95
0.85	0.84	0.86	0.84	0.88	0.84	0.89
0.8	0.79	0.81	0.79	0.82	0.79	0.84
0.78	0.77	0.79	0.77	0.8	0.77	0.81
0.76	0.75	0.77	0.75	0.78	0.75	0.79
0.74	0.73	0.75	0.73	0.76	0.73	0.77
0.72	0.71	0.73	0.71	0.74	0.71	0.75
0.7	0.69	0.71	0.69	0.72	0.69	0.73
0.68	0.67	0.69	0.67	0.7	0.67	0.7
0.66	0.65	0.67	0.65	0.67	0.65	0.68
0.64	0.63	0.65	0.63	0.65	0.63	0.66
0.62	0.61	0.63	0.61	0.63	0.61	0.64
0.6	0.59	0.61	0.59	0.61	0.59	0.62
0.59	0.58	0.6	0.58	0.6	0.58	0.61
0.58	0.57	0.59	0.58	0.59	0.57	0.6
0.57	0.56	0.58	0.57	0.58	0.56	0.59
0.56	0.55	0.57	0.56	0.57	0.56	0.58
0.55	0.55	0.55	0.55	0.56	0.55	0.57
0.54	0.54	0.54	0.54	0.55	0.54	0.55
0.53	0.53	0.53	0.53	0.54	0.53	0.54
0.52	0.52	0.52	0.52	0.53	0.52	0.53
0.51	0.51	0.51	0.51	0.52	0.51	0.52
0.5	0.5	0.5	0.5	0.51	0.5	0.51
0.49	0.49	0.49	0.49	0.5	0.49	0.5
0.48	0.48	0.48	0.48	0.49	0.48	0.49
0.47	0.47	0.47	0.47	0.48	0.47	0.48
0.46	0.46	0.46	0.46	0.47	0.46	0.47
0.45	0.45	0.45	0.45	0.46	0.45	0.46

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Distagon 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	33.43	INF	19.44	INF	11.69	INF
20	12.54	INF	9.89	INF	7.41	INF
10	7.72	INF	6.63	INF	5.42	INF
7	5.8	19.75	5.17	48.13	4.41	INF
5	4.36	9.2	4	12.65	3.53	24.45
4	3.58	6.27	3.33	7.69	3.01	10.85
3.5	3.18	5.11	2.98	6.01	2.72	7.76
3	2.76	4.1	2.61	4.65	2.41	5.63
2.5	2.33	3.21	2.23	3.53	2.08	4.06
2.2	2.07	2.72	1.99	2.95	1.87	3.31
2	1.89	2.42	1.82	2.6	1.72	2.87
1.8	1.71	2.13	1.66	2.26	1.58	2.47
1.6	1.53	1.85	1.49	1.95	1.42	2.1
1.5	1.44	1.72	1.4	1.8	1.34	1.92
1.4	1.35	1.59	1.31	1.66	1.26	1.76
1.3	1.26	1.46	1.23	1.52	1.18	1.6
1.2	1.16	1.33	1.14	1.38	1.1	1.45
1.1	1.07	1.21	1.05	1.25	1.02	1.3
1	0.97	1.09	0.96	1.12	0.93	1.16
0.95	0.93	1.03	0.91	1.05	0.89	1.09
0.9	0.88	0.97	0.87	0.99	0.84	1.03
0.85	0.83	0.91	0.82	0.93	0.8	0.96
0.8	0.78	0.85	0.77	0.87	0.76	0.89
0.78	0.76	0.83	0.75	0.85	0.74	0.87
0.76	0.75	0.81	0.74	0.82	0.72	0.84
0.74	0.73	0.78	0.72	0.8	0.7	0.82
0.72	0.71	0.76	0.7	0.77	0.69	0.79
0.7	0.69	0.74	0.68	0.75	0.67	0.77
0.68	0.67	0.72	0.66	0.73	0.65	0.74
0.66	0.65	0.69	0.64	0.7	0.63	0.72
0.64	0.63	0.67	0.62	0.68	0.61	0.7
0.62	0.61	0.65	0.6	0.66	0.6	0.67
0.6	0.59	0.63	0.59	0.64	0.58	0.65
0.59	0.58	0.61	0.58	0.62	0.57	0.64
0.58	0.57	0.6	0.57	0.61	0.56	0.62
0.57	0.56	0.59	0.56	0.6	0.55	0.61
0.56	0.55	0.58	0.55	0.59	0.54	0.6
0.55	0.54	0.57	0.54	0.58	0.53	0.59
0.54	0.53	0.56	0.53	0.57	0.52	0.58
0.53	0.52	0.55	0.52	0.56	0.51	0.56
0.52	0.51	0.54	0.51	0.54	0.5	0.55
0.51	0.5	0.53	0.5	0.53	0.49	0.54
0.5	0.49	0.52	0.49	0.52	0.48	0.53
0.49	0.48	0.51	0.48	0.51	0.48	0.52
0.48	0.47	0.49	0.47	0.5	0.47	0.51
0.47	0.47	0.48	0.46	0.49	0.46	0.5
0.46	0.46	0.47	0.45	0.48	0.45	0.48
0.45	0.45	0.46	0.44	0.47	0.44	0.47

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Distagon 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	7.41	INF	4.88	INF
20	5.44	INF	3.94	INF
10	4.29	INF	3.31	INF
7	3.64	INF	2.91	INF
5	3.02	INF	2.5	INF
4	2.63	25.17	2.23	INF
3.5	2.41	13.04	2.07	INF
3	2.16	7.94	1.89	18.86
2.5	1.9	5.13	1.69	8.15
2.2	1.72	3.98	1.55	5.56
2	1.6	3.35	1.45	4.4
1.8	1.47	2.81	1.34	3.5
1.6	1.34	2.34	1.23	2.79
1.5	1.27	2.13	1.17	2.49
1.4	1.2	1.92	1.11	2.22
1.3	1.12	1.73	1.05	1.97
1.2	1.05	1.56	0.99	1.74
1.1	0.97	1.39	0.92	1.53
1	0.9	1.23	0.85	1.33
0.95	0.86	1.15	0.81	1.24
0.9	0.82	1.08	0.78	1.15
0.85	0.78	1	0.74	1.07
0.8	0.73	0.93	0.7	0.99
0.78	0.72	0.9	0.69	0.96
0.76	0.7	0.88	0.67	0.93
0.74	0.68	0.85	0.66	0.89
0.72	0.67	0.82	0.64	0.86
0.7	0.65	0.79	0.63	0.83
0.68	0.63	0.77	0.61	0.81
0.66	0.62	0.74	0.6	0.78
0.64	0.6	0.72	0.58	0.75
0.62	0.58	0.69	0.56	0.72
0.6	0.56	0.66	0.55	0.69
0.59	0.56	0.65	0.54	0.68
0.58	0.55	0.64	0.53	0.66
0.57	0.54	0.63	0.52	0.65
0.56	0.53	0.61	0.52	0.64
0.55	0.52	0.6	0.51	0.62
0.54	0.51	0.59	0.5	0.61
0.53	0.5	0.58	0.49	0.6
0.52	0.49	0.57	0.48	0.58
0.51	0.49	0.55	0.47	0.57
0.5	0.48	0.54	0.47	0.56
0.49	0.47	0.53	0.46	0.54
0.48	0.46	0.52	0.45	0.53
0.47	0.45	0.5	0.44	0.52
0.46	0.44	0.49	0.43	0.51
0.45	0.43	0.48	0.42	0.49

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	121.68	INF	103.91	INF	80.76	INF
50	35.48	84.8	33.79	INF	30.92	INF
20	17.2	23.9	16.8	26.73	16.06	32.48
15	13.37	17.08	13.13	18.48	12.67	21.04
12	10.94	13.29	10.77	14.12	10.47	15.56
10	9.25	10.88	9.14	11.42	8.91	12.35
8	7.52	8.55	7.44	8.88	7.29	9.43
7	6.63	7.42	6.57	7.66	6.45	8.06
6	5.73	6.3	5.68	6.48	5.6	6.76
5.5	5.27	5.75	5.23	5.9	5.16	6.13
5	4.81	5.21	4.78	5.32	4.72	5.51
4.5	4.35	4.67	4.32	4.76	4.27	4.91
4	3.88	4.13	3.86	4.2	3.82	4.32
3.8	3.69	3.92	3.67	3.98	3.64	4.08
3.6	3.5	3.7	3.49	3.76	3.45	3.85
3.4	3.31	3.49	3.3	3.54	3.27	3.62
3.2	3.12	3.28	3.11	3.33	3.08	3.4
3	2.93	3.07	2.92	3.11	2.9	3.17
2.8	2.74	2.86	2.73	2.9	2.71	2.95
2.6	2.55	2.65	2.54	2.68	2.52	2.73
2.4	2.36	2.44	2.35	2.47	2.34	2.51
2.2	2.16	2.24	2.16	2.26	2.15	2.29
2	1.97	2.03	1.97	2.05	1.96	2.07
1.9	1.87	1.93	1.87	1.94	1.86	1.96
1.8	1.78	1.82	1.77	1.84	1.76	1.86
1.7	1.68	1.72	1.68	1.73	1.67	1.75
1.6	1.58	1.62	1.58	1.63	1.57	1.64
1.5	1.48	1.52	1.48	1.53	1.48	1.54
1.4	1.39	1.41	1.38	1.42	1.38	1.43
1.3	1.29	1.31	1.29	1.32	1.28	1.33
1.2	1.19	1.21	1.19	1.22	1.18	1.22
1.1	1.09	1.11	1.09	1.11	1.09	1.12
1	0.99	1.01	0.99	1.01	0.99	1.02

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	56.79	INF	38.32	INF	25.68	INF
50	26.63	INF	21.74	INF	17.01	INF
20	14.82	43.89	13.18	79.52	11.29	INF
15	11.89	25.29	10.81	34.05	9.51	63.13
12	9.93	17.76	9.17	21.66	8.22	30.6
10	8.52	13.69	7.96	15.88	7.23	20.19
8	7.03	10.18	6.64	11.34	6.13	13.37
7	6.25	8.61	5.94	9.42	5.53	10.77
6	5.44	7.14	5.21	7.68	4.89	8.56
5.5	5.03	6.44	4.83	6.88	4.56	7.56
5	4.61	5.76	4.44	6.11	4.21	6.64
4.5	4.18	5.1	4.04	5.37	3.85	5.78
4	3.75	4.47	3.64	4.67	3.48	4.97
3.8	3.57	4.22	3.47	4.4	3.33	4.66
3.6	3.39	3.97	3.3	4.13	3.18	4.36
3.4	3.22	3.73	3.14	3.87	3.02	4.07
3.2	3.04	3.49	2.97	3.61	2.86	3.78
3	2.86	3.25	2.79	3.35	2.7	3.5
2.8	2.68	3.01	2.62	3.1	2.54	3.23
2.6	2.49	2.78	2.44	2.86	2.38	2.97
2.4	2.31	2.55	2.27	2.62	2.21	2.71
2.2	2.12	2.33	2.09	2.38	2.04	2.45
2	1.94	2.1	1.91	2.15	1.87	2.2
1.9	1.84	1.99	1.82	2.03	1.78	2.08
1.8	1.75	1.88	1.73	1.92	1.69	1.96
1.7	1.66	1.77	1.63	1.8	1.6	1.84
1.6	1.56	1.66	1.54	1.69	1.52	1.72
1.5	1.47	1.56	1.45	1.58	1.43	1.61
1.4	1.37	1.45	1.36	1.47	1.34	1.49
1.3	1.27	1.34	1.26	1.36	1.25	1.38
1.2	1.18	1.23	1.17	1.25	1.15	1.26
1.1	1.08	1.13	1.07	1.14	1.06	1.15
1	0.99	1.02	0.98	1.03	0.97	1.04

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 85/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	17.47	INF	12.01	INF
50	12.98	INF	9.71	INF
20	9.37	INF	7.54	INF
15	8.11	INF	6.71	INF
12	7.16	72.59	6.05	INF
10	6.4	32.6	5.5	INF
8	5.53	17.85	4.84	33.71
7	5.03	13.49	4.46	20.89
6	4.5	10.17	4.04	13.86
5.5	4.22	8.8	3.81	11.42
5	3.92	7.57	3.57	9.42
4.5	3.61	6.47	3.31	7.77
4	3.28	5.47	3.04	6.37
3.8	3.15	5.1	2.92	5.86
3.6	3.01	4.74	2.8	5.39
3.4	2.87	4.39	2.68	4.95
3.2	2.73	4.06	2.56	4.53
3	2.58	3.74	2.43	4.13
2.8	2.43	3.43	2.3	3.75
2.6	2.28	3.13	2.16	3.4
2.4	2.13	2.84	2.03	3.06
2.2	1.97	2.56	1.88	2.73
2	1.81	2.29	1.74	2.43
1.9	1.73	2.16	1.66	2.28
1.8	1.65	2.03	1.59	2.13
1.7	1.56	1.9	1.51	1.99
1.6	1.48	1.78	1.43	1.85
1.5	1.39	1.65	1.35	1.72
1.4	1.31	1.53	1.27	1.59
1.3	1.22	1.41	1.19	1.46
1.2	1.13	1.29	1.11	1.33
1.1	1.05	1.17	1.02	1.21
1	0.96	1.06	0.94	1.08

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	159.86	INF	142.81	INF	99.47	INF
100	61.58	INF	58.87	INF	49.93	INF
90	57.64	INF	55.26	INF	47.31	INF
80	53.37	INF	51.33	INF	44.4	INF
70	48.74	INF	47.03	INF	41.14	INF
60	43.68	95.94	42.3	INF	37.48	INF
50	38.13	72.67	37.08	97.15	33.33	INF
45	35.16	62.55	34.26	79.86	31.03	INF
40	32.03	53.28	31.29	65.33	28.58	89.23
35	28.75	44.75	28.15	52.94	25.94	67.6
30	25.29	36.88	24.83	42.26	23.09	51.09
25	21.65	29.59	21.31	32.95	20.02	38.07
20	17.8	22.83	17.57	24.77	16.69	27.54
15	13.73	16.53	13.59	17.52	13.06	18.86
14	12.89	15.32	12.77	16.16	12.3	17.3
13	12.04	14.13	11.93	14.84	11.52	15.79
12	11.18	12.96	11.09	13.55	10.73	14.33
11	10.31	11.8	10.23	12.29	9.93	12.92
10	9.42	10.65	9.36	11.05	9.11	11.56
9.5	8.98	10.09	8.92	10.44	8.69	10.9
9	8.53	9.52	8.48	9.84	8.27	10.24
8.5	8.08	8.96	8.04	9.24	7.85	9.6
8	7.63	8.41	7.59	8.65	7.42	8.96
7.5	7.17	7.86	7.14	8.07	6.99	8.34
7	6.72	7.31	6.68	7.49	6.55	7.72
6.5	6.25	6.77	6.23	6.92	6.12	7.11
6	5.79	6.22	5.77	6.35	5.67	6.52
5.5	5.32	5.69	5.3	5.8	5.22	5.93
5	4.86	5.15	4.84	5.24	4.77	5.35
4.8	4.67	4.94	4.65	5.02	4.59	5.12
4.6	4.48	4.73	4.46	4.8	4.41	4.89
4.5	4.38	4.62	4.37	4.69	4.32	4.78
4.4	4.29	4.52	4.28	4.58	4.22	4.67
4.2	4.1	4.31	4.09	4.37	4.04	4.44
4	3.91	4.1	3.9	4.15	3.85	4.22
3.8	3.72	3.89	3.71	3.94	3.67	4
3.6	3.53	3.68	3.52	3.72	3.48	3.77
3.5	3.43	3.57	3.42	3.61	3.39	3.66
3.4	3.33	3.47	3.33	3.51	3.3	3.55
3.2	3.14	3.26	3.13	3.29	3.11	3.34
3	2.95	3.05	2.94	3.08	2.92	3.12
2.9	2.85	2.95	2.85	2.98	2.82	3.01
2.8	2.76	2.85	2.75	2.87	2.73	2.9
2.7	2.66	2.74	2.65	2.77	2.63	2.79
2.6	2.56	2.64	2.56	2.66	2.54	2.69

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
2.5	2.47	2.54	2.46	2.56	2.44	2.58
2.4	2.37	2.43	2.36	2.45	2.35	2.47
2.3	2.27	2.33	2.27	2.35	2.25	2.37
2.2	2.17	2.23	2.17	2.24	2.16	2.26
2.1	2.08	2.12	2.07	2.14	2.06	2.15
2	1.98	2.02	1.98	2.03	1.97	2.05
1.95	1.93	1.97	1.93	1.98	1.92	2
1.9	1.88	1.92	1.88	1.93	1.87	1.94
1.85	1.83	1.87	1.83	1.88	1.82	1.89
1.8	1.78	1.82	1.78	1.83	1.77	1.84
1.75	1.73	1.77	1.73	1.78	1.72	1.79
1.7	1.68	1.72	1.68	1.72	1.68	1.73
1.65	1.64	1.66	1.63	1.67	1.63	1.68
1.6	1.59	1.61	1.58	1.62	1.58	1.63
1.55	1.54	1.56	1.54	1.57	1.53	1.58
1.5	1.49	1.51	1.49	1.52	1.48	1.53
1.45	1.44	1.46	1.44	1.47	1.43	1.47
1.4	1.39	1.41	1.39	1.42	1.38	1.42
1.35	1.34	1.36	1.34	1.36	1.34	1.37
1.3	1.29	1.31	1.29	1.31	1.29	1.32
1.25	1.24	1.26	1.24	1.26	1.24	1.27
1.2	1.19	1.21	1.19	1.21	1.19	1.22
1.15	1.14	1.16	1.14	1.16	1.14	1.16
1.1	1.09	1.11	1.09	1.11	1.09	1.11
1.05	1.04	1.06	1.04	1.06	1.04	1.06
1	1	1	0.99	1.01	0.99	1.01
0.98	0.98	0.98	0.97	0.99	0.97	0.99
0.96	0.96	0.96	0.96	0.97	0.95	0.97
0.95	0.95	0.95	0.95	0.96	0.94	0.96
0.94	0.94	0.94	0.94	0.95	0.93	0.95
0.92	0.92	0.92	0.92	0.93	0.91	0.93
0.9	0.9	0.9	0.9	0.91	0.89	0.91
0.88	0.88	0.88	0.88	0.89	0.87	0.89
0.86	0.86	0.86	0.86	0.86	0.85	0.87
0.85	0.85	0.85	0.85	0.85	0.84	0.86
0.84	0.84	0.84	0.84	0.84	0.84	0.85
0.82	0.82	0.82	0.82	0.82	0.82	0.83
0.8	0.8	0.8	0.8	0.8	0.8	0.81
0.78	0.78	0.78	0.78	0.78	0.78	0.79
0.76	0.76	0.76	0.76	0.76	0.76	0.77
0.75	0.75	0.75	0.75	0.75	0.75	0.75
0.74	0.74	0.74	0.74	0.74	0.74	0.74
0.72	0.72	0.72	0.72	0.72	0.72	0.72
0.7	0.7	0.7	0.7	0.7	0.7	0.7

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	68.77	INF	47.46	INF	32.70	INF
100	40.81	INF	32.24	INF	24.69	INF
90	39.04	INF	31.13	INF	24.04	INF
80	37.04	INF	29.85	INF	23.26	INF
70	34.75	INF	28.34	INF	22.34	INF
60	32.1	INF	26.56	INF	21.22	INF
50	29.01	INF	24.41	INF	19.83	INF
45	27.26	INF	23.16	INF	19	INF
40	25.35	INF	21.77	INF	18.05	INF
35	23.25	INF	20.2	INF	16.97	INF
30	20.94	71.26	18.44	INF	15.71	INF
25	18.38	48.22	16.43	76.11	14.23	INF
20	15.54	32.48	14.12	43.08	12.47	78.12
15	12.35	21.03	11.44	25	10.34	33.74
14	11.67	19.11	10.85	22.32	9.86	29.03
13	10.97	17.28	10.25	19.86	9.35	25
12	10.25	15.55	9.62	17.61	8.83	21.51
11	9.51	13.9	8.97	15.52	8.28	18.47
10	8.76	12.34	8.3	13.59	7.7	15.79
9.5	8.37	11.58	7.95	12.68	7.41	14.57
9	7.98	10.84	7.6	11.79	7.1	13.41
8.5	7.59	10.12	7.24	10.94	6.79	12.32
8	7.19	9.42	6.88	10.12	6.47	11.29
7.5	6.78	8.73	6.51	9.33	6.14	10.31
7	6.37	8.05	6.13	8.56	5.8	9.38
6.5	5.96	7.4	5.74	7.82	5.46	8.49
6	5.54	6.75	5.35	7.1	5.1	7.65
5.5	5.11	6.12	4.95	6.41	4.74	6.85
5	4.68	5.51	4.54	5.74	4.37	6.08
4.8	4.5	5.26	4.38	5.47	4.21	5.79
4.6	4.33	5.02	4.21	5.21	4.06	5.5
4.5	4.24	4.9	4.13	5.08	3.98	5.35
4.4	4.15	4.78	4.05	4.95	3.9	5.21
4.2	3.97	4.55	3.88	4.7	3.75	4.93
4	3.79	4.31	3.71	4.45	3.59	4.65
3.8	3.61	4.08	3.54	4.2	3.43	4.38
3.6	3.43	3.85	3.36	3.96	3.27	4.12
3.5	3.34	3.73	3.28	3.84	3.18	3.98
3.4	3.25	3.62	3.19	3.72	3.1	3.85
3.2	3.07	3.39	3.01	3.48	2.94	3.6
3	2.88	3.17	2.84	3.24	2.77	3.34
2.9	2.79	3.06	2.75	3.12	2.68	3.22
2.8	2.7	2.94	2.66	3.01	2.6	3.09
2.7	2.61	2.83	2.57	2.89	2.51	2.97
2.6	2.51	2.72	2.48	2.78	2.43	2.85

Schärfentiefentabellen / Depth of field tables



COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm

Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
2.5	2.42	2.61	2.39	2.66	2.34	2.73
2.4	2.33	2.5	2.3	2.55	2.25	2.61
2.3	2.23	2.39	2.2	2.43	2.16	2.49
2.2	2.14	2.29	2.11	2.32	2.08	2.37
2.1	2.04	2.18	2.02	2.21	1.99	2.26
2	1.95	2.07	1.93	2.1	1.9	2.14
1.95	1.9	2.02	1.88	2.04	1.85	2.08
1.9	1.86	1.96	1.84	1.99	1.81	2.02
1.85	1.81	1.91	1.79	1.93	1.76	1.97
1.8	1.76	1.85	1.74	1.88	1.72	1.91
1.75	1.71	1.8	1.7	1.82	1.67	1.85
1.7	1.66	1.75	1.65	1.77	1.63	1.8
1.65	1.62	1.7	1.6	1.71	1.58	1.74
1.6	1.57	1.64	1.56	1.66	1.54	1.68
1.55	1.52	1.59	1.51	1.61	1.49	1.63
1.5	1.47	1.54	1.46	1.55	1.44	1.57
1.45	1.43	1.48	1.41	1.5	1.4	1.52
1.4	1.38	1.43	1.37	1.44	1.35	1.46
1.35	1.33	1.38	1.32	1.39	1.31	1.41
1.3	1.28	1.33	1.27	1.34	1.26	1.35
1.25	1.23	1.27	1.22	1.28	1.21	1.3
1.2	1.18	1.22	1.18	1.23	1.17	1.24
1.15	1.14	1.17	1.13	1.18	1.12	1.19
1.1	1.09	1.12	1.08	1.13	1.07	1.14
1.05	1.04	1.07	1.03	1.07	1.03	1.08
1	0.99	1.01	0.98	1.02	0.98	1.03
0.98	0.97	0.99	0.97	1	0.96	1.01
0.96	0.95	0.97	0.95	0.98	0.94	0.99
0.95	0.94	0.96	0.94	0.97	0.93	0.97
0.94	0.93	0.95	0.93	0.96	0.92	0.96
0.92	0.91	0.93	0.91	0.94	0.9	0.94
0.9	0.89	0.91	0.89	0.92	0.88	0.92
0.88	0.87	0.89	0.87	0.89	0.86	0.9
0.86	0.85	0.87	0.85	0.87	0.84	0.88
0.85	0.84	0.86	0.84	0.86	0.83	0.87
0.84	0.83	0.85	0.83	0.85	0.83	0.86
0.82	0.81	0.83	0.81	0.83	0.81	0.84
0.8	0.79	0.81	0.79	0.81	0.79	0.82
0.78	0.77	0.79	0.77	0.79	0.77	0.8
0.76	0.75	0.77	0.75	0.77	0.75	0.77
0.75	0.74	0.76	0.74	0.76	0.74	0.76
0.74	0.73	0.75	0.73	0.75	0.73	0.75
0.72	0.72	0.73	0.71	0.73	0.71	0.73
0.7	0.7	0.71	0.69	0.71	0.69	0.71

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	22.55	INF	15.66	INF
100	18.44	INF	13.57	INF
90	18.07	INF	13.37	INF
80	17.64	INF	13.13	INF
70	17.1	INF	12.83	INF
60	16.44	INF	12.46	INF
50	15.6	INF	11.97	INF
45	15.08	INF	11.66	INF
40	14.48	INF	11.3	INF
35	13.78	INF	10.87	INF
30	12.94	INF	10.35	INF
25	11.92	INF	9.69	INF
20	10.66	INF	8.84	INF
15	9.07	65.32	7.72	INF
14	8.7	49.65	7.46	INF
13	8.31	38.89	7.17	INF
12	7.89	31.04	6.86	82.54
11	7.45	25.06	6.52	50.4
10	6.98	20.36	6.16	34.35
9.5	6.74	18.36	5.97	29
9	6.48	16.56	5.77	24.73
8.5	6.22	14.92	5.57	21.23
8	5.95	13.43	5.35	18.31
7.5	5.68	12.06	5.13	15.85
7	5.39	10.8	4.89	13.73
6.5	5.09	9.64	4.65	11.9
6	4.78	8.57	4.39	10.3
5.5	4.46	7.57	4.12	8.89
5	4.13	6.64	3.84	7.63
4.8	3.99	6.29	3.72	7.16
4.6	3.86	5.95	3.6	6.72
4.5	3.79	5.78	3.54	6.5
4.4	3.72	5.61	3.48	6.29
4.2	3.57	5.29	3.35	5.88
4	3.43	4.97	3.23	5.49
3.8	3.28	4.66	3.1	5.12
3.6	3.13	4.36	2.97	4.75
3.5	3.06	4.21	2.9	4.58
3.4	2.98	4.06	2.83	4.4
3.2	2.83	3.78	2.69	4.07
3	2.67	3.5	2.55	3.74
2.9	2.6	3.36	2.48	3.59
2.8	2.52	3.23	2.41	3.43
2.7	2.44	3.09	2.34	3.28
2.6	2.36	2.96	2.26	3.13

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Planar 100/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
2.5	2.27	2.83	2.19	2.98
2.4	2.19	2.7	2.11	2.84
2.3	2.11	2.57	2.03	2.7
2.2	2.03	2.45	1.96	2.56
2.1	1.94	2.32	1.88	2.42
2	1.86	2.2	1.8	2.29
1.95	1.81	2.14	1.76	2.22
1.9	1.77	2.08	1.72	2.16
1.85	1.73	2.02	1.68	2.09
1.8	1.68	1.96	1.64	2.03
1.75	1.64	1.9	1.6	1.96
1.7	1.6	1.84	1.56	1.9
1.65	1.55	1.78	1.52	1.83
1.6	1.51	1.72	1.47	1.77
1.55	1.47	1.66	1.43	1.71
1.5	1.42	1.6	1.39	1.65
1.45	1.38	1.55	1.35	1.59
1.4	1.33	1.49	1.3	1.53
1.35	1.29	1.43	1.26	1.47
1.3	1.24	1.37	1.22	1.41
1.25	1.2	1.32	1.18	1.35
1.2	1.15	1.26	1.13	1.29
1.15	1.11	1.21	1.09	1.23
1.1	1.06	1.15	1.04	1.17
1.05	1.01	1.09	1	1.11
1	0.97	1.04	0.95	1.06
0.98	0.95	1.02	0.94	1.03
0.96	0.93	1	0.92	1.01
0.95	0.92	0.98	0.91	1
0.94	0.91	0.97	0.9	0.99
0.92	0.89	0.95	0.88	0.97
0.9	0.88	0.93	0.86	0.94
0.88	0.86	0.91	0.85	0.92
0.86	0.84	0.89	0.83	0.9
0.85	0.83	0.88	0.82	0.89
0.84	0.82	0.87	0.81	0.88
0.82	0.8	0.84	0.79	0.85
0.8	0.78	0.82	0.77	0.83
0.78	0.76	0.8	0.76	0.81
0.76	0.74	0.78	0.74	0.79
0.75	0.73	0.77	0.73	0.78
0.74	0.72	0.76	0.72	0.77
0.72	0.71	0.74	0.7	0.74
0.7	0.69	0.72	0.68	0.72

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop					
	2.1		2.8		4	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	44.73	INF	37.32	INF	35.90	INF
10	8.19	12.84	7.91	15.14	7.84	24.27
8	6.81	9.71	6.61	10.96	6.56	15.05
7	6.07	8.27	5.91	9.16	5.88	11.83
6	5.31	6.91	5.19	7.51	5.16	9.21
5	4.51	5.61	4.43	6	4.4	7.03
4	3.68	4.38	3.63	4.61	3.61	5.19
3	2.82	3.21	2.79	3.33	2.78	3.61
2.5	2.38	2.64	2.35	2.72	2.35	2.9
2	1.92	2.09	1.91	2.14	1.9	2.25
1.8	1.74	1.87	1.72	1.91	1.72	1.99
1.6	1.55	1.65	1.54	1.68	1.54	1.75
1.5	1.46	1.55	1.45	1.57	1.45	1.63
1.4	1.36	1.44	1.35	1.46	1.35	1.51
1.3	1.27	1.33	1.26	1.35	1.26	1.39
1.2	1.17	1.23	1.17	1.24	1.17	1.28
1.1	1.08	1.12	1.07	1.14	1.07	1.16
1	0.98	1.02	0.98	1.03	0.98	1.05
0.95	0.93	0.97	0.93	0.98	0.93	1
0.9	0.89	0.92	0.88	0.92	0.88	0.94
0.85	0.84	0.86	0.83	0.87	0.83	0.89
0.8	0.79	0.81	0.79	0.82	0.79	0.83
0.75	0.74	0.76	0.74	0.77	0.74	0.78
0.7	0.69	0.71	0.69	0.71	0.69	0.72
0.65	0.64	0.66	0.64	0.66	0.64	0.67
0.62	0.62	0.63	0.62	0.63	0.61	0.64
0.6	0.59	0.61	0.59	0.61	0.59	0.62
0.58	0.57	0.59	0.57	0.59	0.57	0.59
0.56	0.55	0.57	0.55	0.57	0.55	0.57
0.55	0.55	0.56	0.54	0.56	0.54	0.56
0.54	0.54	0.54	0.53	0.55	0.53	0.55
0.52	0.52	0.52	0.51	0.53	0.51	0.53

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop					
	5.6		8		11	
m	von / from	bis / to	von / from	bis / to	von / from	bis / to
INF	26.64	INF	17.02	INF	10.80	INF
10	7.3	70.13	6.33	INF	5.23	INF
8	6.18	25.23	5.47	INF	4.63	INF
7	5.56	17.31	4.99	36.43	4.28	INF
6	4.92	12.2	4.46	19.33	3.89	77.56
5	4.23	8.64	3.89	11.66	3.45	21.22
4	3.49	6	3.26	7.31	2.95	10.16
3	2.71	3.98	2.57	4.51	2.37	5.43
2.5	2.3	3.14	2.2	3.45	2.05	3.96
2	1.87	2.38	1.8	2.55	1.71	2.82
1.8	1.69	2.1	1.64	2.23	1.56	2.43
1.6	1.52	1.83	1.47	1.93	1.41	2.07
1.5	1.43	1.7	1.39	1.78	1.33	1.9
1.4	1.34	1.57	1.3	1.64	1.25	1.74
1.3	1.25	1.44	1.22	1.5	1.17	1.58
1.2	1.15	1.32	1.13	1.37	1.09	1.43
1.1	1.06	1.2	1.04	1.24	1.01	1.29
1	0.97	1.08	0.95	1.11	0.93	1.15
0.95	0.92	1.02	0.91	1.05	0.88	1.08
0.9	0.87	0.96	0.86	0.99	0.84	1.02
0.85	0.83	0.9	0.82	0.92	0.8	0.95
0.8	0.78	0.85	0.77	0.86	0.75	0.89
0.75	0.73	0.79	0.72	0.81	0.71	0.83
0.7	0.69	0.73	0.68	0.75	0.67	0.76
0.65	0.64	0.68	0.63	0.69	0.62	0.7
0.62	0.61	0.65	0.61	0.66	0.6	0.67
0.6	0.59	0.62	0.58	0.63	0.58	0.64
0.58	0.57	0.6	0.57	0.61	0.56	0.62
0.56	0.55	0.58	0.55	0.59	0.54	0.6
0.55	0.54	0.57	0.54	0.58	0.53	0.59
0.54	0.53	0.56	0.53	0.56	0.52	0.57
0.52	0.51	0.54	0.51	0.54	0.5	0.55

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
INF	7.04	INF	4.71	INF
10	4.17	INF	3.23	INF
8	3.78	INF	3	INF
7	3.55	INF	2.85	INF
6	3.28	INF	2.68	INF
5	2.96	INF	2.46	INF
4	2.59	21.81	2.2	INF
3	2.14	7.57	1.87	16.83
2.5	1.87	4.97	1.67	7.73
2	1.58	3.28	1.44	4.27
1.8	1.46	2.76	1.33	3.42
1.6	1.33	2.3	1.22	2.74
1.5	1.26	2.09	1.17	2.45
1.4	1.19	1.9	1.11	2.18
1.3	1.12	1.71	1.05	1.94
1.2	1.04	1.54	0.98	1.71
1.1	0.97	1.37	0.92	1.51
1	0.89	1.22	0.85	1.32
0.95	0.85	1.14	0.81	1.23
0.9	0.81	1.07	0.78	1.14
0.85	0.77	0.99	0.74	1.06
0.8	0.73	0.92	0.7	0.98
0.75	0.69	0.86	0.67	0.9
0.7	0.65	0.79	0.63	0.83
0.65	0.61	0.72	0.59	0.76
0.62	0.58	0.69	0.57	0.72
0.6	0.56	0.66	0.55	0.69
0.58	0.55	0.64	0.53	0.66
0.56	0.53	0.61	0.52	0.63
0.55	0.52	0.6	0.51	0.62
0.54	0.51	0.59	0.5	0.61
0.52	0.49	0.56	0.48	0.58

Schärfentiefentabellen / Depth of field tables

COMPACT PRIME CP.2 Makro-Planar 50/T2.1 T*

Zerstreuungskreisdurchmesser / circle of confusion: 0.030 mm



Gravur Engraving	T-Blende / T-Stop			
	16		22	
m	von / from	bis / to	von / from	bis / to
0.5	0.48	0.54	0.47	0.55
0.49	0.47	0.53	0.46	0.54
0.48	0.46	0.51	0.45	0.53
0.47	0.45	0.5	0.44	0.52
0.46	0.44	0.49	0.43	0.5
0.45	0.43	0.48	0.42	0.49
0.44	0.42	0.47	0.41	0.48
0.43	0.41	0.46	0.41	0.47
0.42	0.4	0.44	0.4	0.45
0.41	0.4	0.43	0.39	0.44
0.4	0.39	0.42	0.38	0.43
0.39	0.38	0.41	0.37	0.42
0.38	0.37	0.4	0.36	0.41
0.37	0.36	0.39	0.36	0.4
0.37	0.36	0.39	0.35	0.39
0.36	0.35	0.38	0.35	0.38
0.35	0.34	0.36	0.34	0.37
0.34	0.33	0.35	0.33	0.36
0.33	0.32	0.34	0.32	0.35
0.32	0.32	0.34	0.31	0.34
0.32	0.31	0.33	0.31	0.33
0.31	0.3	0.32	0.3	0.32
0.3	0.29	0.31	0.29	0.31
0.29	0.28	0.3	0.28	0.3
0.28	0.28	0.29	0.27	0.29
0.28	0.27	0.28	0.27	0.29
0.27	0.27	0.28	0.26	0.28
0.26	0.26	0.27	0.25	0.27
0.25	0.25	0.25	0.25	0.26
0.24	0.24	0.24	0.24	0.24
0.24	0.23	0.24	0.23	0.24